HIGHWAY ENGINEERING



CONCRETE TECHNOLOGY LAB MANUAL



Dundigal, Quthbullapur (M), Hyderabad-500043.







CERTIFICATE

This is to certify that this manual is a bonafide record of practical work in "HIGHWAY ENGINEERING & CONCRETE TECHNOLOGY" Laboratory in First Semester of Third year B.Tech (Civil) programe during the academic year 2021-22. The book is prepared by Ms.M.Nanditha, Asst.Prof, Department of Civil Engineering

Signature of HOD Signature of Director Signature of Principal

506PC: HIGHWAY ENGINEERING & CONCRETE TECHNOLOGY LAB

B.Tech. III Year I Sem.

L T/P/D C
0 /3/0 1.5

Pre-Requisites: Building Materials, Concrete Technology, Highway Materials

Course Objectives: The objectives of the course are to

- To learn laboratory tests and their procedures cement, fine aggregate, course aggregates and bitumen
- To Evaluate fresh concrete properties
- To Understand the test procedures for characterization of Concrete and bituminous mixes

Course Outcomes: Student shall be able to

- Categorize the test on materials used Civil Engineering Building & Pavement constructions
- To perform the tests on concrete for it characterization.
- To Design Concrete Mix Proportioning by Using Indian Standard Method.
- Examine the tests performed for Bitumen mixes.
- To prepare a laboratory report

I. Test on Cement

- 1. Normal Consistency and fineness of cement.
- 2. Initial setting time and final setting time of cement.
- 3. Specific gravity of cement
- 4. Soundness of cement
- 5. Compressive strength of cement
- 6. Workability test on concrete by compaction factor, slump and Vee-bee.

II. Test on Aggregates (Coarse and Fine)

- 1. Specific gravity (Pycnometer and wire basket), water absorption
- 2. Shape (Flakiness and elongation indices)
- 3. Impact and abrasion value tests
- 4. Crushing resistance and durability tests
- 5. Sieve Analysis and gradation charts (Job mix formula using Rothfuch's charts)
- 6. Bulking of sand, Bulk and compact densities of fine and coarse aggregates

III. Test on Fresh Concrete

- 1. Slump test
- 2. CF (compact factor stress)
- 3. Vee-bee Test
- 4. Flow Table Test

IV. Test on hardened concrete

- 1. Compression test on cubes & Cylinders
- 2. Flexure test
- 3. Split Tension Test
- 4. Modulus of Elasticity

V. Tests on Bitumen and Bituminous concrete

- 1. Penetration, softening point and spot test
- 2. Ductility, Elastic recovery and viscosity
- 3. Flash and fire points and specific gravity
- 4. Marshall's Stability (sample preparation and testing for stability and flow values)

TEXT BOOKS:

- 1. Concrete Manual by M.L. Gambhir, Dhanpat Rai & Sons
- 2. Highway Material Testing manual, Khanna, Justo and Veeraraghavan, Nemchand Brothers

IS CODES:

- 1. IS 10262:2009 "Concrete Mix Proportioning Guidelines"
- 2. 1S 516:2006 "Methods of Tests on Strength of Concrete"
- 3. IS 383:1993 "Specification For Coarse And Fine Aggregates From Natural Sources For Concrete"
- 4. 1S 1201 -1220 (1978) "Methods for testing tars and bituminous materials"
- 5. IRC SP 53 -2010 "Guidelines on use of modified bitumen"
- 6. MS-2 Manual for Marshalls Mix design 2002

BEYOND THE SYLLABUS EXPERIMENT:

1 Testing of concrete cubes by Accelerated curing method.

LAB INCHARGE HOD-CIVIL

INDEX

<u>S.NO</u>	NAME OF THE EXPERIMENT	PAGE NO.					
I. Test on Cement							
1	Normal Consistency and fineness of cement.						
2	Initial setting time and final setting time of cement.						
3	Specific gravity of cement						
4	Soundness of cement						
5	Compressive strength of cement						
	II. Test on Aggregates (Coarse and Fine)						
6	Specific gravity (Pycnometer and wire basket), water absorption						
7	Shape (Flakiness and elongation indices)						
8	Impact and abrasion value tests						
9	Crushing resistance and durability tests						
10	Sieve Analysis and gradation charts (Job mix formula using Rothfuch's charts)						
11	Bulking of sand, Bulk and compact densities of fine and coarse aggregates						
	III. Test on Fresh Concrete						
12	Slump test						
13	CF (compact factor stress)						
14	Vee-bee Test						
15	Flow Table Test						
	IV. Test on hardened concrete						
16	Compression test on cubes & Cylinders						
17	Flexure test						
18	Split Tension Test						
19	Modulus of Elasticity						
	V. Tests on Bitumen and Bituminous concrete						
20	Penetration, softening point and spot test						
21	Ductility, Elastic recovery and viscosity						
22	Flash and fire points and specific gravity						
	ADD ON EXTRA EXPERIMENTS						
23	REBOUND HAMMER						
24	ULTRASOUND PULSE VELOCITY (UPV)						

PREFACE

This book entitled "HIGHWAY ENGINEERING & CONCRETE TECHNOLOGY" Lab Manual is intended for the use of seventh semester (i.e., III-I) B.Tech (civil) students of Marri Laxman Reddy Institute of Technology and Management, Dundigal, Hyderabad. The main objective of the Highway Engineering & Concrete Technology Lab Manual is to furnish the conceptual understanding of the basic principles and procedures of testing concrete and highway materials. This laboratory has mixing facilities and bulk materials for concrete. The main aim of this book is to develop the habit of scientific reasoning and providing answers to all the doubts that arise during the course of conducting experiments. The book was written as per the new syllabus prescribed by the JNTUH university in a simple language. Some of the additional experiments apart from the syllabus also were included in the book. These experiments will help the students to expertise in determining the proportions of ingredients required for the mix design of both asphalt mixtures and cement concrete, and to characterize the pavement materials including soil, aggregate, asphalt, cement, asphalt mixtures, cement concrete.. Hence we hope this book serve for better understanding by the student community with all details of experiments

Ву,

MNanditha

,Asst.Prof,

Department of civil engineering

<u>ACKNOWLEDGEMENT</u>

It was really a good experience, working at HIGHWAY ENGINEERING & CONCRETE TECHNOLOGY LAB. First I would like to thank Ms.M.Nandhitha, Assoc.prof, Department of Civil Engineering, Marri Laxman Reddy Institute of technology & Management for giving the technical support in preparing the document.

I express my sincere thanks to Mr.K.Murali, Head of the Department of Civil Engineering, Marri Laxman Reddy Institute of technology & Management, for his concern towards me and gave me opportunity to prepare Concrete & Highway Material laboratory manual.

I am deeply indebted and gratefully acknowledge the constant support and valuable patronage of Dr.Balarengadurai, Academic Dean, Marri Laxman Reddy Institute of technology & Management. I am unboundedly grateful to him for timely corrections and scholarly guidance.

I express my hearty thanks to Dr.K. Venkateswara Reddy, Principal, Marri Laxman Reddy Institute of technology & Management, for giving me this wonderful opportunity for preparing the environmental engineering laboratory manual.

At last, but not the least I would like to thanks the entire Civil Department faculty those who had inspired and helped me to achieve my goal.

By,
MNanditha
Asst.Prof,
Department of civil engineering

GENERAL INSTRUCTIONS

- 1. Students are instructed to come to the laboratory on time. Late comers are not entertained in the lab.
- 2. Students should be punctual to the lab. If not, conducted experiments will not be repeated.
- 3. Students are expected to come prepared at home with the experiments which are going to performed.
- 4. Students are instructed to display their identity cards and apron before entering into the lab.
- 5. Students are instructed not to bring mobile phones to the lab.
- 6. Do not throw waste such as match fine aggregate, cement paste etc. into the sink. They must be thrown the specified areas instructed by lab instructor.
- 7. Do not lift heavy weights without super vision of lab instructor.
- 8. Do not operate the equipment without super vision of lab instructor.
- 9. Keep the water and gas taps closed except when these utilities are needed.
- 10. Students should update the records and lab observation books session wise. Before leaving the lab the student should get his lab observation book signed by the faculty.
- 11. Students should submit the lab records 2/3 days in advance to the concerned faculty members in the staffroom for their correction and return.
- 12. Students should not move around the lab during the lab session.
- 13. If any emergency arises, the student should take the permission from faculty member concerned in written format.
- 14. The faculty members may suspend any student from the lab session on disciplinary grounds.
- 15. Never cook up the result by recording false observations or by making manipulated calculations.
- 16. All the data should be prettified with the relevant units.

SAFETY PRECAUTIONS

- 1. While working in the laboratory suitable precautions should be observed to prevent accidents.
- 2. Always follow the experimental instructions strictly.
- 3. The laboratory apron should be worn while working in the laboratory to protect the clothing from damage by cement and other materials.
- 4. Use the fire extinguisher (CO_2 type) available in the lab in case of fire.
- 5. Use the first aid box in case of any accident/mishap.
- 6. Never work in the laboratory unless a demonstrator or teaching assistant in present.
- 7. Even after all precautions, still if accident occurs, do not panic and inform the instructor at once and act as per his suggestions.

INSTITUTION VISION AND MISSION

VISION

To establish as an ideal academic institutions in the service of the nation, the world and the humanity by graduating talented engineers to be ethically strong, globally competent by conducting high quality research, developing breakthrough technologies, and disseminating and preserving technical knowledge.

OUR MISSION

To fulfill the promised vision through the following strategic characteristics and aspirations:

- Contemporary and rigorous educational experiences that develop the engineers and managers.
- ➤ An atmosphere that facilitates personal commitment to the educational success of students in an environment that values diversity and community.
- > Prudent and accountable resource management.
- ➤ Undergraduate programs that integrate global awareness, communication skills and team building.
- ➤ Leadership and service to meet society's needs
- > Education and research partnerships with colleges, universities, and industries to graduate
- > education and training that prepares students for interdisciplinary engineering research and advanced problem solving abilities.
- ➤ Highly successful alumni who contribute to the profession in the global society.

DEPARTMENT VISION, MISSION, PROGRAMME EDUCATIONAL OBJECTIVES AND SPECIFIC OUTCOMES

VISION

The Civil Engineering department strives to impart quality education by extracting the innovative skills of students and to face the challenges in latest technological advancements and to serve the society.

MISSION

Provide quality education and to motivate students towards professionalism

Address the advanced technologies in research and industrial issues

PROGRAMME EDUCATIONAL OBJECTIVES

The Programme Educational Objectives (PEOs) that are formulated for the civil engineering programme are listed below:

- **PEO-I:** Solving civil engineering problems in different circumstances
- **PEO-II** Pursue highereducation and research for professional development.
- **PEO-III:** Inculcate qualities of leadership for technology innovation and entrepreneurship.

PROGRAM SPECIFIC OUUTCOMES

- **PSO 1 UNDERSTANDING:** Graduates will have ability to describe, analyse and solve problems using mathematical, scientific, and engineering knowledge.
- **PSO 2 ANALYTICAL SKILLS:** Graduates will have an ability to plan, execute, maintain, manage, and rehabilitate civil engineering systems and processes.
- **PSO 3 EXECUTIVE SKILLS:** Graduates will have an ability to interact and work effectively in multi disciplinary teams.

PROGRAMME OUT COMES

- 1. Engineering knowledge: Apply the knowledge of mathematics, science, engineering fundamentals, and an engineering specialization to the solution of complex engineering problems.
- **2. Problem analysis:** Identify, formulate, review research literature, and analyze complex engineering problems reaching substantiated conclusions using first principles of mathematics, natural sciences, and engineering sciences.
- **3. Design/development of solutions**: Design solutions for complex engineering problems and design system components or processes that meet the specified needs with appropriate consideration for the public health and safety, and the cultural, societal, and environmental considerations.
- **4. Conduct investigations of complex problems**: Use research-based knowledge and research methods including design of experiments, analysis and interpretation of data, and synthesis of the information to provide valid conclusions.
- **5. Modern tool usage:** Create, select, and apply appropriate techniques, resources, and modern engineering and IT tools including prediction and modeling to complex engineering activities with an understanding of the limitations.
- **6.** The engineer and society: Apply reasoning informed by the contextual knowledge to assess societal, health, safety, legal and cultural issues and the consequent responsibilities relevant to the professional engineering practice.
- 7. Environment and sustainability: Understand the impact of the professional engineering solutions in societal and environmental contexts, and demonstrate the knowledge of, and need for sustainable development.
- **8.** Ethics: Apply ethical principles and commit to professional ethics and responsibilities and norms of the engineering practice.
- **9. Individual and team work:** Function effectively as an individual, and as a member or leader in diverse teams, and in multidisciplinary settings.
- **10. Communication:** Communicate effectively on complex engineering activities with the engineering community and with society at large, such as, being able to comprehend and write effective reports and design documentation, make effective presentations, and give and receive clear instructions.
- 11. Project management and finance: Demonstrate knowledge and understanding of the engineering and management principles and apply these to one's own work, as a member and leader in a team, to manage projects and in multidisciplinary environments.
- **12. Life-long learning:** Recognize the need for, and have the preparation and ability to engage in independent and life-long learning in the broadest context of technological change.

COURSE STRUCTURE, OBJECTIVES & OUTCOMES

COURSE STRUCTURE

Highway Materials & Concrete Technology lab will have a continuous evaluation during 5th semester for 30 sessional marks and 70 end semester examination marks.

Out of the 30 marks for internal evaluation, day-to-day work in the laboratory shall be evaluated for 15 marks and internal practical examination shall be evaluated for 15 marks conducted by the laboratory teacher concerned.

The end semester examination shall be conducted with an external examiner and internal examiner. The external examiner shall be appointed by the principal / Chief Controller of examinations

COURSE OBJECTIVE

The objectives of the course are to


- 1. Learn laboratory tests and their procedures cement, fine aggregate, course aggregates and bitumen
- 2. Evaluate fresh concrete properties
- 3. Understand the test procedures for characterization of Concrete and bituminous mixes

COURSE OUTCOME

CE317.1	Evaluate the strength of cement
CE317.2	Analyze the characteristics of aggregates
CE317.3	Perform the tests on fresh concrete
CE317.4	Evaluate the strength of the hardened concrete
CE317.5	perform the Tests on Bitumen and Bituminous concrete

COURSE ARTICULATION MATRIX (CO - PO / PSO MAPPING):

Program outcomes	1	2	3	4	5	6	7	8	9	10	11	12	PSO 1	PSO 2	PSO 3
CE317.1	3	3	3	3	3	0	0	0	0	0	0	3	3	3	3
CE317.2	3	3	2	3	3	0	0	0	0	0	0	3	3	3	3
CE317.3	3	3	2	3	3	0	0	0	0	0	0	3	3	3	3
CE317.4	3	3	2	3	3	0	0	0	0	0	0	3	3	3	3
CE317.5	3	1	3	3	3	0	0	0	0	0	0	3	3	3	3
Total	15	13	12	15	15	0	0	0	0	0	0	15	15	15	15
Average	3	2.6	2.4	3	3	0	0	0	0	0	0	3	3	3	3



1A. NORMAL CONSISTENCY OF CEMENT

AIM:


Normal consistency test is used tooptimum percentage of water content required for a cement paste.

APPARATUS:

- 1. Vicat apparatus (conforming to IS: 5513 1976) with plunger (10 mm in diameter)
- 2. Vicat mould
- 3. Gauging trowel
- 4. Measuring jar
- 5. Balance
- 6. Tray.

INTRODUCTION:

The standard consistency of a cement paste is defined as that consistency which will permit the Vi-cat plunger to penetrate to a point 5 to 7 mm from the bottom of the Vicat mould. For finding out initial setting time, final setting time, soundness of cement and compressive strength of cement, it is necessary to fix the quantity of water to be mixed in cement in each case. This experiment is intended to find out the quantity of water to be mixed for a given cement to give a cement paste of normal consistency and can be done with the help of Vicat apparatus.



PROCEDURE:

- 1. Prepare a paste of weighed quantity of cement (300 grams) with a weighed quantity of potable or distilled water, starting with 28% water of 300g of cement.
- 2. The percentage of water to be taken according to the room temperature $27 \pm 5^{\circ}$ C.
- 3. Take care that the time of gauging is not less than 3 minutes, not more than 5 minutes and the gauging shall be completed before setting occurs.
- 4. The gauging time shall be counted from the time of adding the water to the dry cement until commencing to fill the mould.
- 5. Fill the Vi-cat mould with this paste, the mould resting upon a non-porous plate.
- 6. After completely filling the mould, trim off the surface of the paste, making it in level with the top of the mould. The mould may slightly be shaken to expel the air.

- 7. Place the test block with the mould, together with the non-porous resting plate, under the rod bearing the plunger (10mm diameter), lower the plunger gently to touch the surface of the test block and quickly release, allowing it to penetrate into the paste.
- 8. This operation shall be carried out immediately after filling the mould.
- 9. Prepare trial pastes with varying percentages of water and test as described above until the amount of water necessary for making the standard consistency as defined above is obtained.
- 10. Express the amount of water as a percentage by weight of the dry cement.

CALCULATIONS:

1 gm per cc = 1 ml of water

$$P = \frac{W}{C} X 100$$

WhereP = percentage of water (b)

W =water required in ml (c)

C = weight of cement required (a).

OBSERVATIONS:

S.No	Weight of cement taken in gms (a)	Water taken in % (b)	Water taken in ml (c)	Plunger penetration (mm)	Consistency of cement in % by weight b/a * 100
1	400	28	112		
2	400	30			
3	400	32			
4	400	34			
5	400	36			

RESULT: Normal consistency for the given sample of cement is ______.

1B. FINENESS OF CEMENT

AIM:

To determine the fineness of the given sample of cement by sieving.

APPARATUS:

- 1. IS-90-micron sieve conforming to IS:460-1965
- 2. Standard balance
- 3. Weights
- 4. Brush.

INTRODUCTION:

The fineness of cement has an important bearing on the rate of hydration and hence on the rate of gain of strength and on the rate of evolution of heat. Finer cement offers a greater surface area for hydration and hence the faster and greater the development of strength. Increase in fineness of cement is also found to increase the drying shrinkage of concrete. Fineness of cement is tested either by sieving or by determination of specific surface by air-permeability apparatus. Specific surface is the total surface area of all the particles in one gram of cement.

FINENESS BY SIEVING:

PROCEDURE:

- 1. Weigh accurately 100 g of cement and place it on a standard 90 microns IS sieve.
- 2. Break down any air-set lumps in the cement sample with fingers.
- 3. Continuously sieve the sample giving circular and vertical motion for a period of 15 minutes.
- 4. Weigh the residue left on the sieve. As per IS code the percentage residue should not exceed 10%.

OBSERVATIONS:

S.No	Weight of sample taken(g)	Weight of residue(g)	Fineness (%)
Average	e fineness of cement is	·	
RESUL	T: Fineness of given sample of cem	nent is	

VIVA QUESTIONS:

- 1. What is the percentage of water required for preparing 1:3 cement sand mortar for compressive strength test?
- 2. What is significance of the test?
- 3. What are IS specifications for compressive strength of 1:3 cement sand mortar after 3 days and 7 days?
- 4. What is the minimum number of specimens to be made or each age of testing?
- 5. How do you determine the compressive strength of cement?
- 6. How is the curing of a test specimen done?
- 7. Why should not the specimen be allowed to dry until they are tested?
- 8. What is the rate of loading?
- 9. What do you understand by standard consistency?
- 10. What is the weight of the moving part of the vicat apparatus?
- 11. What are the dimensions of the plunger?
- 12. What is importance of the test?
- 13. What precautions do you observe in performing the above tests?
- 14. What is the field test to test the fineness of cement?
- 15. What is the diameter of the plunger?
- 16. As per the IS code the % of cement on the sieve shouldn't exceed?
- 17. State the importance of this test?
- 18. ______ % of water for 300g of cement.
- 19. _____ microns sieve is used for the experiment.
- 20. What is meant by the normal consistency of the cement?
- 21. What precautions do you observe in performing the above tests?
- 22. What are is specifications for setting times of various types of cements recommended for use on a construction site?
- 23. What is the initial setting time of cement?
- 24. What is the final setting time of cement?
- 25. What is meant my plasticity?
- 26. Explain about elasticity of cement.
- 27. What are the initial setting time for self compacting concrete?
- 28. What are the final setting time for self compacting concrete?
- 29. Cement should sieve in ______ no.
- 30. What is the field test of fineness of cement?
- 31. Fineness of cement
- 32. Give the difference between normal consistency and standard consistency.
- 33. What is standard consistency?
- 34. When the cement paste is tested within the gauging time. What is the value of gauging time?
- 35. How many moulds required for compression strength test of cement?
- 36. Write the formula for normal consistency.
- 37. Calculate standard consistency(%) when 100 ml of water is added in 1000 g of cement.
- 38. What is the normal consistency for OPC?
- 39. For making cement paste, what is the amount of water we need?
- 40. The relative humidity of laboratory should be ______ for standard consistency.
- 41. What are the ingredients of cement?
- 42. Write the chemical composition of cement.
- 43. Write short note on hydration.
- 44. What are the properties of Ordinary Portland cement?
- 45. Differentiate between flash set and false set of cement.
- 46. List out various tests on Cement?
- 47. Initial Setting Time of OPC?
- 48. Final Setting Time of OPC?
- 49. List out Grades of Cement available in Market?

2A. INITIAL AND FINAL SETTING TIMES OF CEMENT

AIM:


To determine the initial and final setting times for the given sample of cement.

APPARATUS:

- 1. Vicat apparatus (conforming to IS: 5513-1976) with attachments
- 2. Balance
- 3. Weights
- 4. Gauging trowel.

INTRODUCTION:

In actual construction dealing with cement, mortar or concrete, certain time is required for mixing, transporting and placing. During this time cement paste, mortar, or concrete should be in plastic condition. The time interval for which the cement products remain in plastic condition is known as the setting time. Initial setting time is regarded as the time elapsed between the moment that the water is added to the cement to the time that the paste starts losing its plasticity. The final setting time is the time elapsed between the moment the water is added to the cement, and the time when the paste has completely lost its plasticity and has attained sufficient firmness to resist certain pressure. The constituents and fineness of cement is maintained in such a way that the concrete remains in plastic condition for certain minimum time. Once the concrete is placed in the final position, compacted and finished it should lose its plasticity in the earliest possible time so that it is least vulnerable to damages from external destructive agencies. This time should not be more than 10 hours which is referred to as final setting time. Initial setting time should not be less than 30 minutes.



PROCEDURE:

Preparation of Test Block:

- 1. Prepare a neat cement paste by gauging 300 grams of cement with 0.85 times the water required to give a paste of standard consistency (0.85P).
- 2. Potable or distilled water shall be used in preparing the paste.
- 3. The paste shall be gauged in the manner and under the conditions prescribed in determination of consistency of standard cement paste.
- 4. Start a stop-watch at the instant when water is added to the cement.
- 5. Fill the mould with the cement paste gauged as above the mould resting on a nonporous plate.

6. Fill the mould completely and smooth off the surface of the paste making it level with the top of the mould. The cement block thus prepared in the mould is the test block.

DETERMINATION OF INITIAL SETTING TIME:

- 1. Place the test blocks confined in the mould and rest it on the non-porous plate, under the rod bearing initial setting needle, lower the needle gently in contact with the surface of the test block and quickly release, allowing it to penetrate into the test block.
- 2. In the beginning, the needle will completely pierce the test block.
- 3. Repeat this procedure until the needle, when brought in contact with the test block and released as described above, fails to pierce the block to a point 5 to 7 mm measured from the bottom of the mould shall be the initial setting time.

DETERMINATION OF FINAL SETTING TIME:

- 1. Replace the needle of the Vicat apparatus by the needle with an annular attachment.
- 2. The cement shall be considered as finally set when, upon applying the needle gently to the surface of the test block, the needle makes an impression there on, while the attachment fails to do so.
- 3. The period elapsed between the time when water is added to the cement and the time at which the needle makes an impression on the surface of test block while the attachment fails to do so shall be the final setting time.

PRECAUTIONS:

Clean appliances shall be used for gauging. All the apparatus shall be free from vibration during the test. The temperature of water and that of the test room, at the time of gauging shall be $27^{\circ}\text{C} + 20^{\circ}\text{C}$. Care shall be taken to keep the needle straight.

OBSERVATIONS:

Time in minutes

Height in mm fails to penetrate

RESULT:

Initial setting time for the given sample of cement =
Final setting time for the given sample of cement =

VIVA QUESTIONS:

- 1. What do you understand by initial and final setting times of a cement sample?
- 2. What precautions do you observe in performing the above tests?
- 3. What are is specifications for setting times of various types of cements recommended for use on a construction site?
- 4. What is the amount of water to be added for initial setting time?
- 5. What is difference between setting and hardening?
- 6. Differentiate between density and specific gravity of a material.
- 7. State the importance of this test.
- 8. Name other methods that can be used for finding the specific gravity of cement.
- 9. What is the effect on the specific gravity value if the air bubbles are not removed completely?
- 10. Why constant temperature bath is used in this experiment?
- 11. What is the initial setting time of cement?
- 12. What is the final setting time of cement?
- 13. How much amount of water is required for cement consistency?
- 14. What are the initial setting time for self compacting concrete?
- 15. What are the final setting time for self compacting concrete?
- 16. What is the apparatus used for this experiment?
- 17. State the purpose of this experiment?
- 18. What is temperature of the test room?
- 19. What precautions do you observe in performing the above tests?
- 20. What is the specific gravity of the cement?
- 21. What is the percentage of water required for preparing 1:3 cement sand mortar for compressive strength test?
- 22. What is significance of the test?
- 23. What are IS specifications for compressive strength of 1:3 cement sand mortar after 3 days and 7 days?
- 24. What is the minimum number of specimens to be made or each age of testing?
- 25. How do you determine the compressive strength of cement?
- 26. What is difference between setting and hardening
- 27. Differentiate between density and specific gravity of a material.
- 28. State the importance of this test.
- 29. Name other methods that can be used for finding the specific gravity of cement.
- 30. Explain about plasticity of cement.
- 31. In cement hardening process, instants are very important.
- 32. Initial setting time of OPC should not be less than _____.
- 33. Final setting time of cement should not be more than
- 34. In the soundness test, the whole assembly is immersed in water for ______
- 35. Initial setting time of Low Heat Cement should not be less than
- 36. If t₁=Time at which water is first added to cement, t₂ =Time when needle fails to penetrate 5 mm to 7 mm from bottom of the mould, t₃=Time when the needle makes an impression, but the attachment fails to do so, then what is initial setting time?
- 37. If t_1 =Time at which water is first added to cement, t_2 =Time when needle fails to penetrate 5 mm to 7 mm from bottom of the mould, t_3 =Time when the needle makes an impression, but the attachment fails to do so, then what is final setting time?
- 38. What is the capacity of measuring cylinder?
- 39. In cement hardening process, ______ instants are very important.

	ļ
40. What is the adminture used to increase the setting time of compares?	
40. What is the admixture used to increase the setting time of concrete?	ļ
41. Define plastic stage	
42. What do you mean by elastic stage?	
43. How the water content is calculated to get the standard consistency?	ļ
44. Mention the dimensions of the needle used in Vicat apparatus.	ļ
45. Give the dimensions of the cylindrical mould.	
46. Dimension of the plunger used for normal consistency.	
47. The plate used under the cylindrical mould is non – porous plate (TRUE / FALSE).	
48. Draw the diagram of release pin indicator.	
49. Draw the diagram of enlarged view of needle.	
50. Give any two instructions of storing cement.	
30. Give any two instructions of storing cement.	
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ
	ļ

3A. SPECIFIC GRAVITY OF CEMENT

AIM:

To determine the specific gravity of given sample of hydraulic cement.

APPARATUS:

- 1. Physical balance
- 2. Specific gravity bottle of 50ml capacity
- 3. Clean kerosene.

INTRODUCTION:

Specific gravity is defined as the ratio between weight of a given volume of material and weight of an equal volume of water. To determine the specific gravity of cement, kerosene is used which does not react with cement.





PROCEDURE:

- 1. Clean and dry the specific gravity bottle and weigh it with the stopper (W1).
- 2. Fill the specific gravity bottle with cement sample at least half of the bottle and weigh with stopper (W2).
- 3. Fill the specific gravity bottle containing the cement, with kerosene (free of water) placing the stopper and weigh it (W3).
- 4. While doing the above do not allow any air bubbles to remain in the specific gravity bottle.
- 5. After weighing the bottle, the bottle shall be cleaned and dried again.
- 6. Then fill it with fresh kerosene and weigh it with stopper (W4).
- 7. Remove the kerosene from the bottle and fill it with full of water and weigh it with stopper (W5).
- 8. All the above weighing should be done at the room temperature of 27c + 10 c.

OBSERVATIONS:

Description of item Trial 1 Trial 2 Trial 3

Weight of empty bottle W1 g

Weight of bottle + Cement W2 g

Weight of bottle + Cement + Kerosene W3 g

Weight of bottle + Full Kerosene W4

Weight of bottle + Full Water W5 g

$$\begin{split} &\text{Specific gravity of Kerosene } S_k = W4 - W1 \, / \, W5 - W1. \\ &\text{Specific gravity of Cement } S_c = W2 - W1 \, / \, ((W4 - W1) - (W3 - W2)) * S_k S_c \\ &= (W2 - W1) * \, (W4 - W1) \, / \, ((W4 - W1) - (W3 - W2)) * (W5 - W1) \end{split}$$

PRECAUTION:

- 1. Only kerosene which is free of water shall be used.
- 2. At time of weighing the temperature of the apparatus will not be allowed to exceed the specified temperature.
- 3. All air bubbles shall be eliminated in filling the apparatus and inserting the stopper.
- 4. Weighing shall be done quickly after filling the apparatus and shall be accurate to 0.1 mg.
- 5. Precautions shall be taken to prevent expansion and overflow of the contents resulting from the heat of the hand when wiping the surface of the apparatus.

RESULT:

Average specific gravity of given sample of cement =

VIVA QUESTIONS:

- 1. Differentiate between density and specific gravity of a material.
- 2. State the importance of this test.
- 3. Name other methods that can be used for finding the specific gravity of cement
- 4. What is the effect on the specific gravity value if the air bubbles are not removed completely
- 5. Why constant temperature bath is used in this experiment.
- 6. Why do we use kerosene or naphtha in this experiment?
- 7. Define the slump of concrete
- 8. State the significance of slump test
- 9. How do you determine the slump of the concrete?
- 10. Differentiate by sketches the terms of true slump, shear and collapse type of slumps.
- 11. What are the precautions to be taken while conducting this experiment?
- 12. What is the purpose of conducting this experiment?
- 13. What is the specific gravity of the kerosene?
- 14. What is the specific gravity of the cement?
- 15. What is the capacity of the specific gravity bottle?
- 16. What should be the room temperature while conducting the experiment?
- 17. Why do we use kerosene to determine the specific gravity of cement?
- 18. Why are we calculating this value for cement?
- 19. What is the significance of specific gravity of cement?
- 20. What is the other name for the specific gravity bottle?
- 21. What is significance of the test?
- 22. What are IS specifications for compressive strength of 1:3 cement sand mortar after 3 days and 7 days?
- 23. What is the minimum number of specimens to be made or each age of testing?
- 24. What do you understand by standard consistency?
- 25. What is the weight of the moving part of the vicat apparatus?
- 26. What are the dimensions of the plunger?
- 27. How do you determine the slump of the concrete?
- 28. Differentiate by sketches the terms of true slump, shear and collapse type of slumps
- 29. Define the workability and consistency of freshly mixed concrete
- 30. The quantity of gypsum is added _____ to _____ %.
- 31. What do you mean by specific gravity?
- 32. Which type of apparatus used in specific gravity of cement test?
- 33. What is the capacity of pycnometer?
- 34. According to IS, how much of specific gravity of cement is preferred?
- 35. What do you mean by soundness?
- 36. Which type of apparatus used in soundness of cement test?
- 37. According to IS, how much of soundness of cement is preferred?
- 38. What is the disadvantage, if soundness is too high?
- 39. Which components enhance the soundness property in cement?
- 40. Why we have to test the soundness of test?
- 41. Give the formula for specific gravity of cement.

 42. Density of cement is ranging between 3.1-3.16g/cc by this, cement is 3.16 times heavier than water of the same volume.(TRUE/ FALSE). 43. If the specific gravity is 3.19, then the pores in cement are filled with the moisture content. (TRUE/ FALSE). 44. If the cement is exposed to extreme moisture content due to bad weather conditions, then the specific gravity of cement may go up to 3.19. (TRUE/ FALSE). 45. The IS code for Specific gravity test is 46. The specific gravity of Kerosene is 47. The specific gravity of water is 48. A good cement should have the Specific gravity of 49. The practical will be done within temperature.
50. It is a value to calculate whether the material is able to sink or float on water. Every material has some specific
gravity. The value is normally in digits like $0.1 - 100$. If the value is less than 1, then the material will float on water. If the value is greater than 1, then the meterial will sink (TDLIE/EALSE)
water. If the value is greater than 1, then the material will sink. (TRUE/ FALSE).

4A. SOUNDNESS OF CEMENT

AIM:

To determine the soundness of the given sample of cement by "Le Chatelier" Method.

APPARATUS:

- 1. Le Chatelier apparatus conforming to IS 5514-1969
- 2. Balance
- 3. Weights
- 4. Water bath.

INTRODUCTION:

It is essential that the cement concrete shall not undergo appreciable change in volume after setting. This is ensured by limiting the quantities of free lime, magnesia and sulphates in cement which are the causes of the change in volume known as unsoundness. Unsoundness in cement does not come to surface for a considerable period of time. This test is designed to accelerate the slaking process by the application of heat and discovering the defects in a short time. Unsoundness produces cracks, distortion and disintegration there by giving passage to water and atmospheric gases which may have injurious effects on concrete and reinforcement. The apparatus for conducting the test consists of small split cylinder of spring brass or other suitable metal of 0.5mm thickness forming a mould 30 mm internal diameter and 30mm high. On either side of the split mould are attached to indicators with pointed ends, the distance from these ends to the centre of the cylinder being 165 mm. The mould shall be kept in good condition with the jaws not more than 50mm apart.



PROCEDURE:

- 1. Place the lightly oiled mould on a lightly oiled glass sheet and fill it with cement paste formed by gauging cement with 0.78 times the water required to give a paste of standard consistency.
- 2. The paste shall be gauged in the manner and under the conditions prescribed in determination of consistency of standard cement paste, taking care to keep the edges of the mould gently together

- 3. While this operation is being performed cover the mould with another piece of glass sheet, place a small weight on this covering glass sheet and immediately submerge the whole assembly in water at a temperature of 27°C- 20°C and keep there for 24 hours.
- 4. Measure the distance separating the indicator points.
- 5. Submerge the moulds again in water at the temperature prescribed above.
- 6. Bring the water to boiling, with the mould kept submerged for 25 to 30 minutes, and keep it boiling for three hours.
- 7. Remove the mould from the water allow it to cool and measure the distance between the indicator points.
- 8. The difference between these two measurements represents the expansion of the cement.
- 9. For good quality cement this expansion should not be more than 10mm.

OBSERVATIONS:

Initial distance between the indicator points in mm = Final distance between the indicator points in mm = Expansion in mm = final length - initial length =

RESULT:

Expansion in mm.

1.	What is the purpose of conducting this experiment?
2.	What are the precautions to be taken while conducting the experiment?
3.	What should be the lime content in the cement?
4.	What should be the temperature of water?
5.	What is the thickness of the spilt cylinder?
6.	What are the dimensions of the split cylinder?
7.	For the good quality of cement the expansion should not be more than
8.	How many minutes the mould should be submerged in the boiling water?
9.	times of water required for the consistency of cement.
10.	What is the metal used to make the split cylinder?
11.	Is there any field test for the soundness test?
12.	Mention the distance between the glass plates?
	The quantity of gypsum is added to%.
14.	The quantity of gypsum is added depends upon the content.
15.	The unsoundness in cement is due to the presence of
16.	The magnesia content allowed in cement is limited to
17.	What is meant sampling?
	Explain heat of hydration.
	What is the composition of lime in cement?
20.	Mention 5 types of cements.
21.	How do you determine the slump of the concrete?
22.	Differentiate by sketches the terms of true slump, shear and collapse type of slumps
	Define the workability and consistency of freshly mixed concrete
24.	Excess of amount causes cement unsound.
25.	What do you understand by initial and final setting times of a cement sample
26.	What precautions do you observe in performing the above tests?
27.	What are is specifications for setting times of various types of cements recommended for use on a construction site
	Explain about rapid hardening cement.
	What are the uses of low heat cement?
	What are the properties of quick setting cement?
31.	How does soundness affect the strength of cement?
	What is the purpose of the Soundness Test in cement?
33.	How can the soundness of cement be reduced?
34.	What is the correct value of soundness of cement?
35.	What is the use of soundness test of cement?
	What is the soundness test of cement?
	What is expensive cement?
	What is composite cement?
	What is the effect in soundness of cement due to aeration of cement specified in IS 12269?
	Name the apparatus for soundness test of cement.
	Apparatus used for Soundness of Cement?
	State the reasons of unsoundness of cement.
	Explain the role of gypsum in cement.
	Brief the Le- Chatelier apparatus along with its limitations.
	What should be the temperature during the practical is conducting?
	Initial distance between the indicator points in mm
	Final distance between the indicator points in mm
	Give the limit of expansion
	Give the internal diameter of the cylinder mould.
50.	What is the external diameter of the mould.

5A. COMPRESSIVE STRENGTH OF CEMENT

AIM:

To determine the compressive strength of standard cement mortar cubes compacted by means of standard vibration machine.

APPARATUS:

1. Vibration machine and cube moulds of size 7.06 cms (Conforming to IS: 4031- 1988).

STANDARD SAND:

The standard sand to be used in the test shall conform to IS: 650-1991 or sand passing 100 percent through 2 mm sieve and retained 100 percent on 90 microns IS sieve. 2mm to 1mm 33.33 percent 1mm to 500 microns 33.33 percent 500mm to 90 microns 33.33 percent.

INTRODUCTION:

The compressive strength of cement mortars is determined in order to verify whether the cement conforms to IS specifications and whether it will be able to develop the required compressive strength of concrete. The average compressive strength of at least three mortar cubes (area of the face 50 cm²) composed of one part of cement and three parts of standard stand should satisfy IS code specifications.



PROCEDURE:

Mix proportions and mixing:

- 1. Clean appliances shall be used for mixing and the temperature of the water and that of the test room at the time when the above operations are being performed shall be $27 \pm 2^{\circ}$ C.
- 2. Place in a container a mixture of cement and standard sand in the proportion of 1:3 by weight mix it dry, with a trowel for one minute and then with water until the mixture is of uniform colour.
- 3. The quantity of water to be used shall be as specified below.
- 4. In any element, it should not take more than 4 minutes to obtain uniform coloured mix.
- 5. If it exceeds 4 minutes the mixture shall be rejected, and the operation repeated with a fresh quantity of cement, sand and water.
- 6. The material for each cube shall be mixed separately and the quantity of cement standard sand and water shall be as follows: Cement 200 gms Standard sand 600 gms, Water (P/4 + 3) percent of combined weight of cement and sand, where p is the percentage of water required to produce a paste of standard consistency.

MOULDING SPECIMENS:

- 1. In assembling the moulds ready for use, cover the joints between the halves of the mould with a thin film of petroleum jelly and apply a similar coating of petroleum jelly between the contact surfaces of the bottom of the mould and its base plate in order to ensure that no water escapes during vibration.
- 2. Treat the interior faces of the mould with a thin coating of mould oil.
- 3. Place the assembled mould on the table of the vibration machine and firmly hold it is position by means of suitable clamps.
- 4. Securely attach a hopper of suitable size and shape at the top of the mould to facilitate filling and this hopper shall not be removed until completion of the vibration period.
- 5. Immediately after mixing the mortar, place the mortar in the cube mould and rod with a rod.
- 6. The mortar shall be rodded 20 times in about 8 seconds to ensure elimination of entrained air and honey combing.
- 7. Place the remaining quantity of mortar in the hopper of the cube mould and rod again as specified for the first layer and then compact the mortar by vibrations.
- 8. The period of vibration shall be two minutes at the specified speed of 12,000 + 400 vibrations per minute.
- 9. At the end of vibration remove the mould together with the base plate from the machine and finish the top surface of the cube in the mould by smoothing surface with the blade of a trowel.

CURING SPECIMEN:

- 1. Keep the filled moulds at a temperature of 27 + 20 C in an atmosphere of at least 90 % relative humidity for about 24 hours after completion of vibration.
- 2. At the end of that period remove them from the moulds.
- 3. Immediately submerge in clean fresh water and keep them under water until testing.
- 4. The water in which the cubes are submerged shall be renewed every 7 days and shall be maintained at a temperature of 27 OC + 20 C.
- 5. After they have been taken out and until they are tested the cubes shall not be allowed to become dry.

TESTING:

- 1. Test three cubes for compressive strength at the periods mentioned under the relevant specification for different hydraulic cements, the periods being reckoned from the completion of vibration.
- 2. The compressive strength shall be the average of the strengths of three cubes for each period of curing.
- 3. The cubes shall be tested on their sides without any packing between the cube and the steel plates of the testing machine.
- 4. One of the platens shall be carried base and shall be self-adjusting and the load shall be steadily and uniformly applied starting from zero at a rate of 350 Kgs/Cm²/ min. The cubes are tested at the following periods Ordinary Portland cement 3, 7 and 28 days. Rapid hardening Portland cement 1 and 3 days. Low heat Portland cement 3 and 7 days.

CALCULATION:

Calculate the compressive strength from the crushing load and the average area over which the load is applied.

Express the results in N/mm² to the nearest 0.05 mm².

Compressive strength in $N/mm^2 = P/A$

Where P is the crushing load in N and

A is the area in mm^2 (5000 mm^2).

PRECAUTIONS:


Inside of the cube moulds should be oiled to prevent the mortar from adhering to the sides of the mould.

RESULT:

The average compressive strength of the given cement at 3 days N/mm² at 7 days N/mm² at 28 days N/mm².

VIVA QUESTIONS:

- 1. What do you understand by initial and final setting times of a cement sample
- 2. What precautions do you observe in performing the above tests?
- 3. What are is specifications for setting times of various types of cements recommended for use on a construction site
- 4. What is the amount of water to be added for initial setting time
- 5. What is difference between setting and hardening
- 6. Differentiate between density and specific gravity of a material.
- 7. State the importance of this test.
- 8. Name other methods that can be used for finding the specific gravity of cement.
- 9. What is the effect on the specific gravity value if the air bubbles are not removed completely.
- 10. Why constant temperature bath is used in this experiment?
- 11. What is the average strength of the given cement at 3 days?
- 12. What are the precautions to be taken while conducting the experiment?
- 13. What is the significance of the experiment?
- 14. What is the compressive strength for rapid hardening cement at 3 days?
- 15. What is the compressive strength for low heat Portland cement at 7 days?
- 16. What is the compressive strength for ordinary Portland cement at 28 days?
- 17. What is the compressive strength for low heat Portland cement at 3 days?
- 18. What is the compressive strength for ordinary Portland cement at 7 days?
- 19. What is the compressive strength for rapid hardening cement at 7 days?
- 20. What is the compressive strength for ordinary Portland cement at 3 days?
- 21. What is the composition of lime in cement?
- 22. Mention 5 types of cements.
- 23. How do you determine the slump of the concrete?
- 24. Differentiate by sketches the terms of true slump, shear and collapse type of slumps
- 25. Define the workability and consistency of freshly mixed concrete
- 26. Excess of amount causes cement unsound.
- 27. What do you understand by initial and final setting times of a cement sample
- 28. What precautions do you observe in performing the above tests?
- 29. What are is specifications for setting times of various types of cements recommended for use on a construction site
- 30. What are the properties of GGBS based cement?
- 31. Compressive strength test for 1:3 cement and sand
- 32. Which Bouge's compounds are highly responsible for the setting of cement?
- 33. No. of Cube samples required for testing Compression Strength for 100 m³ of concrete?
- 34. What is the standard w/c value for nominal mix of concrete?
- 35. Equipment used to test Compression Strength of Cement?
- 36. What does grade 33 cement indicate?
- 37. Ordinary Portland cement (OPC) has been classified into how many grades?
- 38. Grade 43 OPC is used widely for ______.
- 39. After how many days is the strength of cement is tested and graded according to the result?
- 40. The compressive strength of OPC increases with time (TRUE / FALSE).
- 41. Grade 43 OPC shall be rejected if it remains in bulk storage in the factory for ...
- 42. The ratio of percentage of alumina to iron oxide in OPC 43 grade is ______.
- 43. What is the required minimum fineness for grade 53 OPC?
- 44. Which of the following cannot be added in 33 grade OPC after burning stage?
- 45. How much maximum percentage by mass of performance improvers can be added in grade 33 OPC?
- 46. What are the specifications of standard sand?
- 47. Give the formula to calculate the water content.
- 48. What is dimensions of the mould?
- 49. Give the list of IS codes for cement.
- 50. What is compressive strength?



6A. SPECIFIC GRAVITY (PYCNOMETER AND WIRE BASKET), WATER ABSORPTION

Specific Gravity is the ratio of the weight of a given volume of aggregate to the weight of an equal volume of water. It is the measure of strength or quality of the specific material. Aggregates having low specific gravity are generally weaker than those with higher specific gravity values.

AIM: The main objective of this test is to:

- 1. To measure the strength or quality of the material.
- 2. To determine the water absorption of aggregates.

Apparatus Required

- 1. A balance of capacity about 3kg, to weigh accurate 0.5g, and of such a type and shape as to permit weighing of the sample container when suspended in water.
- 2. A thermostatically controlled oven to maintain temperature at 100-110° C.
- 3. A wire **basket of not** more than 6.3 mm mesh or a perforated container of convenient size with thin wire hangers for suspending it from the balance.
- 4. A container for filling water and suspending the basket
- 5. An air tight container of capacity similar to that of the basket.
- 6. A shallow tray and two absorbent clothes, each not less than 75x45cm.



Apparatus for testing Specific Gravity and Water Absorption of Aggregates

Procedure of Water Absorption and Specific Gravity Test on Aggregates

There are three methods of testing for the determination of the specific gravity of aggregates, according to the size of the aggregates larger than 10 mm, 40 mm and smaller than 10 mm. For Samples larger than 10 mm, 40 mm, the below given test method is used and for samples smaller than 10 mm Pycnometer test is done.

Procedure

- 1. About 2 kg of aggregate sample is washed thoroughly to remove fines, drained and placed in wire basket and immersed in distilled water at a temperature between 22- 32° C and a cover of at least 5cm of water above the top of basket.
- 2. Immediately after immersion the entrapped air is removed from the sample by lifting the basket containing it 25 mm above the base of the tank and allowing it to drop at the rate of about one drop per second. The basket and aggregate should remain completely immersed in water for a period of 24 hour afterwards.
- 3. The basket and the sample are weighed while suspended in water at a temperature of $22^{\circ} 32^{\circ}$ C. The weight while suspended in water is noted = $\mathbf{W_1g}$.
- 4. The basket and aggregates are removed from water and allowed to drain for a few minutes, after which the aggregates are transferred to the dry absorbent clothes. The empty basket is then returned to the tank of water jolted 25 times and weighed in water= $\mathbf{W}_2\mathbf{g}$.
- 5. The aggregates placed on the absorbent clothes are surface dried till no further moisture could be removed by this cloth. Then the aggregates are transferred to the second dry cloth spread in single layer and allowed to dry for at least 10 minutes until the aggregates are completely surface dry. The surface dried aggregate is then weighed = $\mathbf{W}_3 \mathbf{g}$
- 6. The aggregate is placed in a shallow tray and kept in an oven maintained at a temperature of 110° C for 24 hrs. It is then removed from the oven, cooled in an air tight container and weighted= W_4 g.

Observations of Test

S.No	Details	Trail	Trail
		1	2
1	Weight of saturated aggregate suspended in $\label{eq:water} \text{water with basket} = W_1 g$		
2	Weight of basket suspended in water = $\mathbf{W_2} \mathbf{g}$		
3	Weight of saturated surface dry aggregate in air $= \mathbf{W_3}\mathbf{g}$		
4	Weight of oven dry aggregate = $\mathbf{W_4} \mathbf{g}$		
5	Weight of saturated aggregate in water = $W_1 - W_2 g$		
6	Weight of water equal to the volume of the $\mbox{aggregate} = W_3 \!\!-\!\! (\ W_1 \!\!-\!\! W_2) g$		

Formulas:

- (1) Specific gravity = $W_3/(W_3-(W_1-W_2))$
- (2) Apparent specific gravity = $W_4/(W_4-(W_{11}-W_2))$
- (3) Water Absorption = $((W_3 W_4) / W_4) \times 100 **$

The size of the aggregate and whether it has been artificially heated should be indicated. ** Though high specific gravity is considered as an indication of high strength, it is not possible to judge the suitability of a sample aggregate without finding the mechanical properties such as aggregate crushing, impact and abrasion values.

Result:

- (1) Specific gravity =
- (2) Apparent specific gravity =
- (3) Water Absorption =

Recommended Values of Specific Gravity and Water Absorption for Aggregates

The specific gravity of aggregates normally used in road construction ranges from about 2.5 to 3.0 with an average of about 2.68. Water absorption shall not be more than 0.6 per unit by weight.

VIVA QUESTIONS:

- 1. 1 What is the application of specific gravity test in mix design?
- 2. Define Specific gravity
- 3. What is the use of finding specific gravity
- 4. What are the factors affecting specific gravity test
- 5. The specific gravity of aggregates normally used in road construction ranges from about _____ with an average value of about 2.68.
- 6. Specific gravity of aggregates is considered as an indication of _____
- 7. The instrument used for Specific Gravity test for < 6.3mm aggregate
- 8. Water absorption of aggregate is a measure of _____
- 9. This set of Basic Chemical Engineering Multiple Choice Questions & Answers (MCQs) focuses on "Specific Gravity".
- 10. What is the specific gravity of a substance with density 100 kg/m3 with respect to reference substance of density 100 lb/m3?
- 11. It is necessary to mention the temperature at which specific gravity is calculated, because
- 12. What is the specific gravity of a substance with mass 10 kg and volume 2 m3, with respect to the reference density 50 g/m3?
- 13. What is the mass of a cone of radius 1 m and height 3 m having specific gravity 0.1? (Density of water = 1000 kg/m3)
- 14. API gravity is measured in,
- 15. API gravity is necessary for the calculation of specific gravity of petroleum products, because
- 16. What is the API gravity of a substance with specific gravity 1?
- 17. What is the average mass of a substance with specific gravity 10, and its volume varies with time as V = t/500, from t = 2, to t = 0 seconds? (Density of water = 1000 kg/m3)
- 18. Mass of a substance is changing with respect to its volume as $m = -v \ 3 + 3v2 \ -2v$, what is the maximum specific gravity of the substance between $v = 1 \ m3$ and $v = 2 \ m3$? (Density of reference substance = 0.25 kg/m3)
- 19. What is the specific gravity of 10 Kg of water occupied in 10 m3 with respect to 200 g/m3?
- 20. What is the specific gravity of 5 Kg of water occupied in 10 m3 with respect to 500 g/m3?
- 21. What is the specific gravity of 10 Kg of water occupied in 5 m3 with respect to 100 g/m3?
- 22. What is the specific gravity of O2 at 27oC and 60 Pa with respect to 1 Kg/m3?
- 23. What is the specific gravity of N2 at 27oC and 6 Pa with respect to 0.1 Kg/m3? This set of Basic Chemical Engineering Multiple Choice Questions & Answers (MCQs)
- 24. Focuses on "Specific Gravity".
- 25. What is the unit of specific gravity
- 26. What is the specific gravity of a substance with density 100 kg/m3 with respect to reference substance of density 100 lb/m3?
- 27. It is necessary to mention the temperature at which specific gravity is calculated, because
- 28. What is the specific gravity of a substance with mass 10 kg and volume 2 m3, with respect to the reference density 50 g/m3?
- 29. What is the mass of a cone of radius 1 m and height 3 m having specific gravity 0.1? (Density of water = 1000 kg/m3)
- 30. API gravity is measured in,
- 31. API gravity is necessary for the calculation of specific gravity of petroleum products, because
- 32. What is the API gravity of a substance with specific gravity 1?
- 33. What is the average mass of a substance with specific gravity 10, and its volume varies with time as V = t/500, from t = 2, to t = 0 seconds? (Density of water = 1000 kg/m3)

- 34. Mass of a substance is changing with respect to its volume as $m = -v + 3v^2 2v$, what is the maximum specific gravity of the substance between $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance between $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance between $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance between $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance between $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance between $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance $v = 1 + 3v^2 2v$, what is the maximum specific gravity of the substance $v = 1 + 3v^2 2v$, where $v = 1 + 3v^2 2v$, wher
- 35. What is the specific gravity of 10 Kg of water occupied in 10 m3 with respect to 200 g/m3?
- 36. What is the specific gravity of 5 Kg of water occupied in 10 m3 with respect to 500 g/m3?
- 37. What is the specific gravity of 10 Kg of water occupied in 5 m3 with respect to 100 g/m3?
- 38. What is the specific gravity of O2 at 27oC and 60 Pa with respect to 1 Kg/m3?
- 39. What is the specific gravity of N2 at 27oC and 6 Pa with respect to 0.1 Kg/m3?
- 40. Which of the following is not a unit of density?
- 41. What is the density of a substance of mass 10 grams and volume 5 liters?
- 42. A solid of density d is dropped in a liquid of density D, if d>D then, A l
- 43. Liquid of mass 10 kg is enclosed in a cylinder of radius 1 m and length 5 m, what is the density of liquid?
- 44. What is the density of a liquid of mass 20 kg, enclosed in a cuboid of surface areas of three sides as 1 m2, 2 m2, 5 m2, and one of its sides is 2 m?
- 45. What is the density of a liquid of mass 10 kg and contained in a cylinder of radius 5 m and surface area (excluding top and bottom) of 10π m2?
- 46. What is the mass of a liquid having density 20 kg/m3, enclosed in a sphere of radius 1 m?
- 47. What is the mass of a cube having surface area 24 m2, and density 1 kg/m3?
- 48. An empty vessel has with mass 5 kg with volume $0.1\ m3$, is now completely filled with a liquid of density $100\ kg/m3$, what is the final density of the cylinder?
- 49. A cylinder completely filled with water has density = 10 kg/m3 and volume 5 m3, now a cube with side 1 m and density 25 kg/m3 is dipped into the cylinder with some water dropping out, what is the final density of cylinder?(neglect the mass of cylinder).
- 50. Specific gravity =
- 51. Apparent specific gravity =
- 52. Water Absorption =
- 53. The size of the aggregate and whether it has been artificially heated should be indicated.


7A. SHAPE (FLAKINESS AND ELONGATION INDICES)

FLAKINESS INDEX TEST

AIM: To determine flakiness index of a given aggregates sample.

DEFINITION: The flakiness index of aggregate is the percentage dry weight of particles whose least dimension (thickness) is less than three-fifths (0.6) of their mean dimension. The test is not applicable to sizes smaller than 6.3 mm.

APPARATUS: The apparatus consists of a standard thickness gauge shown in fig 5.1, IS sieves of the sizes 63, 50, 40 31.5, 25, 20, 16, 12.5, 10 and 6.3 mm and a balance to weight the samples.



Thickness gauge

PROCEDURE:

- 1. The sample is sieved with the sieves mentioned in the table 6.1 A minimum of 200 pieces of each fraction to be tested are taken and weighed =W1g. in order to separate flaky materials, each friction is then gauged for thickness on thickness gauge shown in fig 6.1 or in bulk on sieves having elongated slots.
- 2. The width of the slot used should be of the dimensions specified in column (3) of table 6.1 for the appropriate size of the material. The amount of flaky material passing the gauge is weighed to accuracy of at least 0.1 percent of the test sample.

DIMENSIONS OF THICHNESS AND LENGTH GAUGES

Size of aggregate		a. Thickness gauge	b. Length gauge (1.8
Passing through IS	Retaining on IS	(0.6 times the mean	times the mean sieve
sieve mm	sieve mm	sieve) mm.) mm.
63.0	50.0	33.90	_
50.0	40.0	27.00	81.0
40.0	31.5	19.50	58.5
31.5	25.0	16.95	_
25.0	20.0	13.50	40.5
20.0	16.0	10.80	32.4
16.0	12.5	8.55	25.6
12.5	10.0	6.75	20.2
10.0	6.3	4.89	14.7

CALCULATIONS AND RESULT:

In order to calculate the flakiness index of the entire sample of aggregates first the weight of each fraction of aggregates passing and retained on the specified set of sieves is noted. As an example let 200 pieces of the aggregates passing 50 mm sieve and retained on 40 mm sieve be= W1g. Each of the particles from this fraction of the thickness gauge in this example the width of the appropriate gauge of the thickness gauge is

$$\frac{(50+40)}{2} * 0.6 = 27mm$$

Let the weight of the flaky material passing this gauge be W1g. similarly the weights of the fractions passing and retained the specified sieves. W1, W2, W3 etc weighted and the total weight W1+W2+W3=W g is found also the weights of material passing each of the specified thickness gauges are found= w1, w2, w3.....And the total weight of the material passing the different thickness gauges= w1+w2+w3+.....and the total weight of the flakinessindex is the total weight of the sample gauged.

Fraction index =
$$\frac{(x1 + x2 + x3 + ...) * 100}{(w1 + w2 + w3 + ...)}$$

OBSERVATION:

Size of aggregate		Weight of the	Weight of
Passing through IS sieve mm	Retaining on IS sieve mm	fraction consisting of 200 pieces, kg	aggregates in each fraction passing through thickness gauge, kg
63.0	50.0		
50.0	40.0		
40.0	31.5		
31.5	25.0		
25.0	20.0		
20.0	16.0		
16.0	12.5		
12.5	10.0		
10.0	6.3		
TC	TAL	W=	X=

RESULT: Flakiness index of the given aggregate (w/W)X100=

ELONGATION INDEX

AIM: To determine elongation index of index of given aggregate sample.

DEFINITION: The elongation index of an aggregate is the percentage by weight of particles whose greatest dimension (length) is greater than one and four fifth (1.8 times) of their mean dimension. The elongation test is not applicable to sizes smaller than 6.3 mm.

APPARATUS: The apparatus length gauge consists of the Standard-length gauge. IS sieve of size 50, 40, 25, 20, 16, 12.5, 10 and 6.3 mm. A balance to weigh the samples

PROCEDURE: The sample is sieved through the specified set of IS sieves. A minimum of 200 pieces of each fraction is taken and weighed. In order to separate elongated material, each fraction is then gauged individually for length gauge. ➤ The gauge length used should be those specified in column 4 of the table for the appropriate material. The pieces of aggregates from each fraction tested which could not pass through the specified gauge length with its long side are elongated particles and are collected separately to find the total weight of aggregate retained by the length gauge are weighed to an accuracy of at least 0.1 percent of the weight of the test sample.

7B. SIEVE ANALYSIS AND GRADATION CHARTS

AIM:

The gradation and size test are used to determine aggregate particle size distribution.

APPARATUS:

AASHTO T 27 and ASTM C 136: Sieve Analysis of Fine and Coarse Aggregates

INTRODUCTION:

In a gradation and size analysis, a sample of dry aggregate of known weight is separated through a series of sieves with progressively smaller openings. Once separated, the weight of particles retained on each sieve is measured and compared to the total sample weight. Particle size distribution is then expressed as a percent retained by weight on each sieve size. Results are usually expressed in tabular or graphical format. Graphical displays almost always use the standard 0.45 power gradation graph.

PROCEDURE:

- 1. Obtain an aggregate sample of adequate mass from one of the following locations: aggregate stockpiles, bins, dump trucks, conveyor belt, or the roadway.
- 2.Mix and reduce the sample to an amount suitable for testing. This process of reducing a sample size is often referred to as "splitting" the sample.
- 3. Dry the test sample to a constant mass and determine the sample's dry mass.
- 4.If using the washed procedure, place the dry sample in a container and cover with water. Agitate the sample to completely separate all particles finer than the No. 200 (0.075 mm) sieve from the coarser aggregate, and to bring the fine material into suspension. Immediately decant the wash water containing the suspended solids over a nest of sieves consisting of a No. 200 (0.075 mm) sieve and an upper sieve with openings in the range of No. 8 (2.36 mm) to No. 16 (1.18 mm).
- 5. If using the washed procedure, repeat step 4 until the wash water is clear.
- 6. If using the washed procedure, return the material retained on the nested sieves to the washed sample by flushing with water. Dry the washed sample to a constant mass and allow to cool. Determine mass of the sample after washing.
- 7.Select applicable sieves to obtain the information required by the specifications covering the material to be tested. Sieve sizes typically used for Superpave mix design are 1½ in, 1.0 inch, ¾ inch, ½ inch, 3/8-inch, No. 4, No. 8, No. 16, No. 30, No. 50, No. 100 and No. 200 (37.5, 25.0, 19.0, 12.5, 9.5, 4.75, 2.36, 1.18, 0.600, 0.300, 0.150 and 0.075 mm) sieves. Assemble the sieves in order of decreasing size of opening from top to bottom and place the nest of sieves over a pan.

- 8. 8. Pour the sample into the top sieve in the nest.
- 9. Sieve the material in a mechanical sieve shaker.
- 10. Determine the mass of the material retained on each sieve size. Record the cumulative mass retained for each sieve size (the mass retained on a specific sieve size and the mass retained on all sieves with larger openings).

CALCULATIONS:

Gradation may be reported as either a percentage retained or percentage passing each sieve size.

Percentage Retained on Each Sieve

$$\text{Percent retained} = \frac{M_{\textit{sieve}} \times 100}{M_{\textit{total}}}$$

Percent passing = 100 – percent retained.

Where:

 $M_{\text{sieve}} = \text{cumulative mass retained on a sieve}, M_{\text{total}} = \text{total original sample mass}$

Percentage Passing Each Sieve

Percent passing = 100 – percent retained.

NOTE: Report percentages to the nearest whole number, except for the percentage passing the No. 200 (0.075 mm) siev which is reported to the nearest 0.1 %.

RESULT:


Percent retained or percent passing each sieve size by mass and material finer than the 0.075 (No. 200) sieve.

GRADATION OF AGGREGATE:

Coarse aggregates used in concrete making contain aggregates of various sizes. This particle size distribution of the coarse aggregates is termed as "Gradation". The sieve analysis is conducted to determine this particle size distribution. ... I is this matrix that is vulnerable to all ills of concrete.

GRADATION CHARTS:

Gradation Chart



GRADATION EXAMPLE 1:

Sample: 5/8" gravel , Initial weight: 9920g.

Sieve designation	Sieve weight empty (g)	Sieve weight full (g)	Aggrega te weight retained (g)	Cumulativ e weight retained (g)	Cumulativ e percent retained (g)	Cumulativ e percent passing (%)
1/2 in	471	471	0			
3/8 in	428	918	490			
No. 4	423	1973	1550			
No. 8	422	2772	2350			
No. 16	417	1757	1340			
No. 30	390	2090	1700			
No. 50	365	1125	760			
No. 100	363	1113	750			
Pan	330	1390	1060			
	TOTAL		10	000 (must be within	0.3% of initial weig	ght above)

GRADATION EXAMPLE 2:

Sample: 5/8" gravel , Initial weight: 9920g.

Sieve designation	Sieve weight empty (g)	Sieve weight full (g)	Aggrega te weight retained (g)	Cumulati ve weight retained (g)	Cumulati ve percent retained (g)	Cumulati ve percent passing (%)
1/2 in				0	0.0	100.0
3/8 in				490	4.9	95.1
No. 4				2040	20.4	79.6
No. 8				4390	43.9	56.1
No. 16				5730	57.3	42.7
No. 30				7430	74.3	25.7
No. 50				8190	81.9	18.1
No. 100				8940	89.4	10.6
Pan				10000	100.0	0.0
TOTAL			10000	(must be within 0	0.3% of initial wei	ight above)

VIVA:

- 1. In how many ways can sieve analysis can be carried out?
- 2. How is the percentage retained on each sieve is calculated?
- 3. What is a receiver in a sieve analyser?
- 4. The aggregate sample for the sieve analysis is placed on?
- 5. The sieve tests of coarse aggregate rages from?
- 6. Which is the limitation of performing the sieve analysis?
- 7. What are the types of gradation?
- 8. What is the other name for narrow gradation?
- 9. What is time of mechanical vibrator to be shaked?
- 10. For fine aggregates that is, sample passing through 4.75mm IS sieve, how much sample should be taken?
- 11. Gradation affects the properties of an aggregate. (True or false).
- 12. Coarse aggregate can be classified into how many groups?
- 13. How much percent of material which passes through a specific sieve is contained in that single-size aggregate?
- 14. Graded aggregate contains particles of size ______
- 15. Flaky particles have _____
- 16. Which size coarse aggregate is ideal for use in concrete mix?
- 17. Elongation index of coarse aggregates is calculated using ______.
- 18. In crushing test on coarse aggregates, what size particle is taken as sample?
- 19. What is the density of undisturbed gravel?
- 20. What is the symbol used for well graded gravel as per ISC system of classification?
- 21. What are the sizes of aggregates used in this test?
- 22. How many sizes of aggregates are there?
- 23. what is aggregate impact test?
- 24. What is abrasion test?
- 25. What are the different sizes of sieves used in this test
- 26. Define grades of soils.
- 27. How the grades of soils are classified?
- 28. List out the sizes of sieves used for coarse aggregate.
- 29. Define workability.
- 30. Explain about bulk density of sand.
- 31. According to geological origin, aggregates is/are classified into ______ types.
- 32. According to size, aggregates is/are classified into ______ types.
- 33. What is the total percentage of aggregates in concrete by volume?
- 34. What is the size of fine aggregates?
- 35. What is the size of coarse aggregates?

36. Crushed stone, gravel and ordinary sand are examples of
37. Which type of aggregate is shown here?
38. Which type of aggregate is shown here?
39. Aggregate crushed before the application of full load of
40. In crushing test, dry aggregates passing through mm sieve and retained mm in
cylinder.
41. According to IS: 2386 part-IV, each layer is tamped times in crushing test.
42. A value less than 10 signifies an exceptionally while above 35 would normally be regarded as
43. Los Angeles machine consists of circular drum of internal diameter mm and length mm.
44. Which machine is preferred for abrasion test?
45. A maximum value of percent is allowed for WBM base course in Indian conditions.
46. Aggregates to be used for wearing course, the impact value shouldn't exceed percent.
47. What is the range of water absorption of aggregates used in road?
48. The loss in weight should not exceed percent when tested with sodium sulphate and
percent with magnesium sulphate solution.
49. If 60% aggregates doesn't pass through the 2.36mm sieve, then what would be the value of Aggregate impact value?
50. If the size of the coarse aggregate is, workability of concrete decreases (TRUE / FALSE).

8A. BULKING OF SAND

AIM:

To ascertain the bulking phenomena of given sample of sand.

APPARATUS:

1000ml measuring jar, brush.

INTRODUCTION:

Increase in volume of sand due to presence of moisture is known as bulking of sand. Bulking is due to the formation of thin film of water around the sand grains and the interlocking of air in between the sand grains and the film of water. When more water is added sand, particles get submerged and volume again becomes equal to dry volume of sand. To compensate the bulking effect extra sand is added in the concrete so that the ratio of coarse to fine aggregate will not change from the specified value. Maximum increase in volume may be 20 % to 40 % when moisture content is 5 % to 10 % by weight. Fine sands show greater percentage of bulking than coarse sands with equal percentage of moisture.

PROCEDURE:

- 1. Take 1000ml measuring jar.
- 2. Fill it with loose dry sand up to 500ml without tamping at any stage of filling.
- 3. Then pour that sand on a pan and mix it thoroughly with water whose volume is equal to 2% of that of dry loose sand.
- 4. Fill the wet loose sand in the container and find the volume of the sand which is in excess of the dry volume of the sand.
- 5. Repeat the procedure for moisture content of 4%, 6%, 8%, etc. and note down the readings.
- 6. Continue the procedure till the sand gets completely saturated i.e. till it reaches the original volume of 500ml.

OBSERVATIONS:

S.No	Volume of dry loose sand V1	% moisture content added	Volume of wet loose sand V2	% Bulking V2 – V1 / V1
1		2%		
2		4%		
3		6%		
4		8%		
5				
6				

GRAPH:		
Draw a graph between percentage moisture content on the graph should be added as a smooth curve. bulking and the corresponding moisture content.		
PRECAUTIONS:		
 While mixing water with sand grains, mixing sheet The sample should not be compressed while being The sample must be slowly and gradually poured Increase in volume of sand due to bulking should 	ng filled in j d into measu	ar. ıring jar from its top.
RESULT:		
The maximum bulking of the given sand is	at	% of moisture content.

VIVA QUESTIONS:

- 1. State the importance of the compressive strength test
- 2. What is the minimum number of test to be conducted for each batch
- 3. State the sequence of mixing the ingredients of concrete
- 4. Why moulds are oiled before use 5. State the methods of compacting the concrete in the cube and cylinde moulds
- 5. How do you determine the compressive strength of the concrete?
- 6. Why capping is necessary for cylindrical specimens
- 7. State the rate of applying of load on compression specimens
- 8. State the nature of compression failures observed by you during testing
- 9. The cubes should be tested on sides and not along the direction of casting comment on this statement
- 10. State the relationship between cube strength and cylinder strength
- 11. State the importance of the test
- 12. State the relative bulking tendencies of fine aggregate
- 13. Explain void content as it implies to fine aggregate
- 14. How do you determine the bulking of the aggregate?
- 15. How would you test sand for silt and organic matter?
- 16. How bulking of fine aggregate is taken into account while designing a concrete mix
- 17. What is the reason for bulking of sand?
- 18. Gradation affects the properties of an aggregate. (True or false).
- 19. How is the percentage retained on each sieve is calculated?
- 20. What is a receiver in a sieve analyser?
- 21. What is a receiver in a sieve analyser?
- 22. The aggregate sample for the sieve analysis is placed on?
- 23. The sieve tests of coarse aggregate rages from?
- 24. Which is the limitation of performing the sieve analysis?
- 25. What are the types of gradation?
- 26. What is the other name for narrow gradation?
- 27. In which void ratio depends?
- 28. What is the specific gravity of coarse aggregate?
- 29. What is the bulk density of coarse aggregate (10mm and 20mm)?
- 30. What is the specific gravity of fine aggregate?
- 31. What do you mean by bulking?
- 32. "Fine aggregate do not show any bulking when it is absolutely dry". Is this statement true or false?
- 33. What is the percentage of bulk if fine aggregates manufactured by extremely fine sand?
- 34. Bulking _____ with increase in moisture.
- 35. Fine sand bulks _____ than coarse sand.
- 36. If h= height of sand when moist and h1 is the height when saturated then what is the percentage o bulking?
- 37. Which apparatus we don't need to calculate the bulking of fine aggregates?
- 38. What is bulking of coarse aggregates?
- 39. If the moisture content of 5 to 10% by weight, then the bulking of sand is increased by _____
- 40. When sand is fully dry then it's volume is _____
- 41. What is soundness?

42. Which apparatus we need to find soundness?
43. Why do we need to find soundness?
44. What is the maximum size of split?
45. Le Chatelier apparatus consist of
46. When the cement paste is filled in mould and kept in water. Then what should be the temperature o
water?
47. Expansion should not be more than
48. If the Y is the reading of sand surface (ml) then what is the percentage of bulking?
49. What is the size of caliper?
50. What is the standard value of expansion for super sulphated cement?

9A. BULK AND COMPACT DENSITIES OF FINE & COARSE AGGREGATE

AIM:

To determine the specific gravity, void ratio, porosity and bulk density of given coarse and fine aggregates.

APPARATUS:

10 Kg capacity balance with weights, cylindrical containers of 1 litre and 5 litre capacities, measuring jar of 1000ml capacity.

INTRODUCTION:

The specific gravity of an aggregate is generally required for calculations in connection with cement concrete design work for determination of moisture content and for the calculations of volume yield of concrete. The specific gravity also gives information on the quality and properties of aggregate. The specific gravity of an aggregate is considered to be a measure of strength of quality of the material. Stones having low specific gravity are generally weaker than those with higher specific gravity values. The bulk density of an aggregate is used for judging its quality by comparison with normal density for that type of aggregate. It is required for converting proportions by weight into proportions by volume and is used in calculating the percentage of voices in the aggregate.

- 1. Specific gravity is the weight of aggregate relative to the weight of equal volume of water.
- 2. Void ratio is the ratio of volume of voids to the volume of solids in an aggregate.
- 3. Percentage of voids or porosity is the ratio of volume of voids to the total volume of a sample of an aggregate.
- 4. Bulk density or unit weight is the weight of material per unit volume.

PROCEDURE:

COARSE AGGREGATE

- 1. Find the weight of the empty container W1.
- 2. Take coarse aggregate in the container up to approximately half of the container and find out the weight W2.
- 3. Fill the container with water up to the level of the coarse aggregates so that all void space inside the aggregate is filled with water. Find its weight W3.
- 4. Fill the container with water after emptying it from mix of coarse aggregate and water.
- 5. Water should be up to the mark, up to which coarse aggregate is filled. Find its weight W4
- 6. Repeat the same process for another trail by taking the aggregate upto the full of the container and by filling the water up to same point.

OBSERVATIONS:

- Sl. No Trail 1 Trail 2
 - 1. Weight of empty container W1.
 - 2. Weight of container with material W2.
 - 3. Weight of container + material + water W3.
 - 4. Weight of container + water W4.
- i) Void ratio = Vol. of Voids / Vol of Solids W3 W1 / ((W4 W1)-(W3-W2))
- ii) Porosity = Vol. of Voids / Total Vol. of aggregate *100 W3 W2 / (W4 W1) * 100
- iii) Specific gravity = W2 W1 / ((W4 W1) (W3 W2))
- iv) Bulk density = W2 W1 / (W4 W1)

FINE AGGREGATE:

VOID RATIO AND POROSITY:

- 1. Take 150 ml of dry sand (v1 ml) in clean measuring jar of 1000 ml capacity.
- 2. Add a measured quantity of 100 ml clean water to the above sample (v2 ml) i.e. v2=100 ml 3. Shake the jar thoroughly till all air bubbles are expelled.
- 4. Now note the readings against the top surface of water in the jar (V3 ml)

Void ratio = v1 + v2 - v3 / v3 - v2Porosity = v1 + v2 - v3 / v1

SPECIFIC GRAVITY OF FINE AGGREGATES:

- 1. Weigh the empty measuring jar of 1000 ml capacity = W1
- 2. Take the weight of empty measuring jar with 150 ml of sand Empty jar + sand = W2
- 3. Take the weight of empty measuring jar with 150 ml of sand and 100 ml of water Empty jar + sand + water = W3
- 4. Remove the mix of sand and water from bottle and fill it with water up to volume V3 then weigh it. Empty jar + water = W4
- 5. Specific gravity = Weight of solids / Volume of Solids W2 W1 / ((W4 W1) (W3 W2))


RESULT:

- 1. Specific gravity of course aggregate.
- 2. Void ratio of course aggregate.
- 3. Porosity of coarse aggregate.
- 4. Bulk density of course aggregate.
- 5. Specific gravity of fine aggregate.
- 6. Void ratio of the given fine aggregate.
- 7. Porosity of the given time aggregate.

VIVA:

- 1. What is porosity?
- 2. What is permeability?
- 3. What is bulk density?
- 4. What is the difference between the density and bulk density?
- 5. What is specific gravity?
- 6. What is void ratio?
- 7. In which void ratio depends?
- 8. What is the specific gravity of coarse aggregate?
- 9. What is the bulk density of coarse aggregate (10mm and 20mm)?
- 10. What is the specific gravity of fine aggregate?
- 11. What is the bulk density of fine aggregate?
- 12. How the void ratio will be calculated?
- 13. In the ratio 1:4:8, which number indicates quantity of fine aggregates?
- 14. PGBS stands for
- 15. Flaky particles have .
- 16. Which size coarse aggregate is ideal for use in concrete mix?
- 17. Compaction factor for heavily reinforced section with vibration is ______
- 18. A slump of 50-100mm can be used for
- 19. The accumulation of water on outer surface of concrete is ______
- 20. State the importance of conducting the experiment?
- 21. The 28 days cube strength of mass concrete using aggregates of maximum size 5 cm for gravity dams should be
- 22. Bulk density of normal weight aggregate is 1600 kg/m³ (TRUE / FALSE)
- 23. The unit weight of heavy weight concrete varies from _____ kg/m³.
- 24. The use of crushed aggregates may results in 10 to 20% higher compressive strength. Is this statement (TRUE / FALSE)?
- 25. S.I. unit of bulk density
- 26. What is void ratio?
- 27. The average specific gravity of natural aggregate is:
- 28. Sp. Gr. =(a-b)/c (TRUE / FALSE)
- 29. The ratio of the mass of the aggregate dried in an oven at ______ for 24 hours to the mass of the water occupying a volume equal to that of solid.
- 30. Aggregate abrasion value is determined by_____
- 31. How many principal thermal properties are there for aggregates?
- 32. Coefficient of thermal expansion of concrete is ____ coefficient of thermal expansion in aggregates.
- 33. If the coefficient of thermal expansion of coarse aggregates and cement paste differs too much, then what happen?
- 34. If the coefficient of the two materials differ by more than $5.4 * 10^{-6}$ per °C, then
- 35. For majority of aggregates, the coefficient of thermal expansion lies between approximately
- 36. For hydrated Portland cement, the coefficient of thermal expansion lies between approximately

37.	The linear thermal coefficient of expansion lies between approximately.
38.	The specific heat of the aggregates is
39.	The thermal conductivity of the aggregates is
40.	"The coefficient of thermal expansion affects the heat resistance". Is this (TRUE / FALSE)?
41.	A maximum value of percent is allowed for WBM base course in Indian conditions.
1 2.	Aggregates to be used for wearing course, the impact value shouldn't exceed percent.
43.	What is the range of water absorption of aggregates used in road?
44.	The loss in weight should not exceed percent when tested with sodium sulphate and _
	nt with magnesium sulphate solution.
45.	If 60% aggregates doesn't pass through the 2.36mm sieve, then what would be the value
Aggre	egate impact value?



10A. SLUMP TEST

AIM:

Concrete slump test is to determine the workability or consistency of concrete mix prepared at the laboratory or the construction site during the progress of the work.


APPARATUS:

Mould for slump test, non-porous base plate, measuring scale, temping rod.

INTRODUCTION:


Concrete slump test is carried out from batch to batch to check the uniform quality of concrete during construction. The slump test is the simplest workability test for concrete, involves low cost and provide immediate results. Generally **concrete slump value** is used to find the workability, which indicates water-cement ratio, but there are various factors including properties of materials, mixing methods, dosage, admixtures etc. also affect the concrete slump value.

- 1. Very low workability: slump value 0-25mm or 0-1 inch
- 2. Low workability: slump value 25-50mm or 1-2 inch
- 3. Medium workability: slump value 50-100mm or 2-4 inch
- 4. High workability: slump value 100-175mm or 4-7 inch




- True Slump True slump is the only slump that can be measured in the test. The measurement is taken
 between the top of the cone and the top of the concrete after the cone has been removed as shown in
 figure.
- Zero Slump Zero slump is the indication of very low water-cement ratio, which results in dry mixes
 These type of concrete is generally used for road construction.
- Collapsed Slump This is an indication that the water-cement ratio is too high, i.e. concrete mix is too wet or it is a high workability mix, for which a slump test is not appropriate.

• **Shear Slump** – The shear slump indicates that the result is incomplete, and concrete to be retested.



PROCEDURE:

- 1. Clean the internal surface of the mould and apply oil.
- 2. Place the mould on a smooth horizontal non- porous base plate.
- 3. Fill the mould with the prepared concrete mix in 4 approximately equal layers.
- 4. Tamp each layer with 25 strokes of the rounded end of the tamping rod in a uniform manner over the cross section of the mould. For the subsequent layers, the tamping should penetrate into the underlying layer.
- 5. Remove the excess concrete and level the surface with a trowel.
- 6. Clean away the mortar or water leaked out between the mould and the base plate.
- 7. Raise the mould from the concrete immediately and slowly in vertical direction.
- 8. Measure the slump as the difference between the height of the mould and that of height point of the specimen being tested.



RESULT:

Slump for the given sample = ____mm.

X 7 X 7	.
VIV	
1. 2.	A slump of 50-100mm can be used for
3.	Concrete is filled in how many layers in slump cone in slump test How many hoppers are there in compaction factor test?
	What is the standard w/c value for nominal mix of concrete?
4. 5.	
	Slump value required for RCC Slab? What is true slump?
6. 7.	Size of Concrete Cubes?
8.	What are the dimensions of the slump cone?
9.	List out workability tests?
9. 10.	How many strokes for each layer?
10.	What is the slump value for low workability?
12.	Slump value 100 – 175mm indicates workability.
13.	What is zero slump?
13. 14.	What is collapsed slump?
15.	What is shear slump?
15. 16.	What is segregation of concrete?
10. 17.	Workability means?
18.	What is the density of concrete?
19.	What is the density of conferce: What is the slump value for medium workability?
20.	What is the slump value in inch for higher workability?
21.	What do you mean by workability?
22.	Workability of concrete can be improved by addition
23.	List out Workability Tests?
24.	Slump value required for RCC Slab?
25.	What is Segregation of concrete?
26.	What is segregation of concrete: What is the standard w/c value for nominal mix of concrete?
27.	How many types of tests are there to find workability?
28.	These test find workability
29.	Workability of concrete is measured by
30.	Which test gives good results for rich mixes?
31.	Which test used for low workable concretes?
32.	Which test Used for high workable concretes?
33.	Which test used for fiber reinforced concrete?
34.	is practical in field test.
35.	What is the compaction factor for medium degree of workability?
36.	What is the Vee-Bee time for medium degree of workability?
37.	The water–cement ratio is the ratio of
38.	A lower ratio leads to
39.	Workability can be resolved
40.	How to improve the workability of concrete.
41.	What is workability?

What is the compaction factor for low degree of workability? What is the Vee-Bee time for medium degree of workability? Clay minerals are found in most Theoretical value for bulk modulus of clay Young's modulus for dickite is The grain density of the clay powders was measured using To avoid trapped air produced by clay flocculation, we used in distilled water. For the cold-pressed aggregate samples, porosity, bulk and grain densities were measured with
What is the compaction factor for medium degree of workability? What is the Vee-Bee time for medium degree of workability? Clay minerals are found in most Theoretical value for bulk modulus of clay Young's modulus for dickite is The grain density of the clay powders was measured using To avoid trapped air produced by clay flocculation, we used in distilled water.
What is the Vee-Bee time for medium degree of workability? Clay minerals are found in most Theoretical value for bulk modulus of clay Young's modulus for dickite is The grain density of the clay powders was measured using To avoid trapped air produced by clay flocculation, we used in distilled water.
Clay minerals are found in most Theoretical value for bulk modulus of clay Young's modulus for dickite is The grain density of the clay powders was measured using To avoid trapped air produced by clay flocculation, we used in distilled water.
Theoretical value for bulk modulus of clay Young's modulus for dickite is The grain density of the clay powders was measured using To avoid trapped air produced by clay flocculation, we used in distilled water.
Young's modulus for dickite is The grain density of the clay powders was measured using To avoid trapped air produced by clay flocculation, we used in distilled water.
The grain density of the clay powders was measured using To avoid trapped air produced by clay flocculation, we used in distilled water.
To avoid trapped air produced by clay flocculation, we used in distilled water.

10B. (COMPACT FACTOR STRESS) TEST

AIM:


Compaction factor test is the workability test for concrete conducted in laboratory.

APPARATUS:

Compaction factor apparatus consists of trowels, hand scoop (15.2 cm long), a rod of steel or other suitable material (1.6 cm diameter, 61 cm long rounded at one end) and a balance.

INTRODUCTION:

The compaction factor test is used for concrete which have low workability for which slump test is not suitable. The test is sufficiently sensitive to enable difference in workability arising from the initial process in the hydration of cement to be measured. Each test, therefore should be carried out at a constant time interval after the mixing is completed, if strictly comparable results are to be obtained. Convenient time for releasing the concrete from the upper hopper has been found to be two minutes after the completion of mixing.



PROCEDURE:

- 1. Place the concrete sample gently in the upper hopper to its brim using the hand scoop and level it.
- 2. Cover the cylinder.
- 3. Open the trapdoor at the bottom of the upper hopper so that concrete fall into the lower hopper. Push the concrete sticking on its sides gently with the road.
- 4. Open the trapdoor of the lower hopper and allow the concrete to fall into the cylinder below.
- 5. Cut of the excess of concrete above the top level of cylinder using trowels and level it.
- 6. Clean the outside of the cylinder.
- 7. Weight the cylinder with concrete to the nearest 10 g. This weight is known as the weight of partially compacted concrete (**W1**).

- 8. Empty the cylinder and then refill it with the same concrete mix in layers approximately 5 cm deep, each layer being heavily rammed to obtain full compaction.
- 9. Level the top surface.
- 10. Weigh the cylinder with fully compacted. This weight is known as the weight of fully compacted concrete (W2).
- 11. Find the weight of empty cylinder (**W**).

CALCULATION:

The compaction factor is defined as the ratio of the weight of partially compacted concrete to the weight of fully compacted concrete. It shall normally to be stated to the nearest second decimal place.

Compaction Factor Value= (W1-W) / (W2-W)


RESULT:

Compaction factor of the concrete =

The Compaction factor values ranges from 0.7 to 0.95.

VIVA:	
1.	Compaction factor for heavily reinforced section with vibration is
2.	Modulus of elasticity, E is calculated using
3.	Concrete is filled in how many layers in slump cone in slump test
4.	How the compaction factor value is calculated?
5.	Higher compaction implies higher
6.	Which test is used for the high workable concretes?
7.	What is the compaction factor for medium degree of workability?
8.	Which test used for low workable concretes?
9.	Which test gives good results for rich mixes?
10.	Workability of concrete is measured by
11.	How many types of tests are there to find workability?
12.	What are the dimensions of upper and lower hopper?
13.	What is the length and diameter of the cylinder?
14.	If compaction factor of concrete is .90, then workability is
15.	A compaction factor of .85 for a cement concrete sample indicates
16.	What is meant by workability?
17.	Workability of concrete can be improved by
18.	Workability of concrete is directly proportional to
19.	Workability of concrete is inversely proportional to
20.	The water–cement ratio is the ratio of
21.	IS 456 of 2000 gives the modulus of elasticity as
22.	What is elastic strains?
23.	Static modulus of elasticity of concrete has been related to its
24.	If the value of fck is 100 then what will be the modulus of elasticity?
25.	Water cement ratio is
26.	A lower ratio leads to
27.	For concrete exposed to a very aggressive environment the w/c should be lower than
28.	What is the range of water in M10?
29.	What is the range of water in M15?
30.	What is the range of water in M20?
31.	What is the range of water in M25?
32.	What is the approx. quantity of water in M5?
33.	What is the approx. quantity of water in M7?
34.	What is the approx. quantity of water in M10?
35.	What is the gel/space ratio?
36.	Who has established the relation between the strength and gel/space ratio?
37.	Power showed that the strength of concrete bears a specific relationship with the gel/space
ratio.	He found the relationship to be

- 38. What does 240 in power's experiment stands for?
- 39. What does x^3 in power's experiment stands for?
- 40. What unit is present with the 240?
- 41. Gel/Space ratio = x = Volume of gel / Space available = 0.657 C / 0.319 C+ Wo. Here C stands for?
- 42. Gel/Space ratio = x = Volume of gel / Space available = 0.657 C / 0.319 C+ Wo. Here Wo stands for?
- 43. According to fig. what is the approx. value of strength of 50mm cube in MPa for gel-space ratio .6?
- 44. Referring to the graph below, what is the approx. value of strength of 50mm cube in MPa for gel-space ratio .8?



- 45. How many types of tests are there to find workability?
- 46. Workability of concrete is measured by
- 47. Which test gives good results for rich mixes?
- 48. Which test used for low workable concretes?
- 49. Which test Used for high workable concretes?
- 50. Which test used for fiber reinforced concrete?

11A. VEE - BEE TEST

AIM:


To determine the workability of freshly mixed concrete by using of Vee – Bee consistometer apparatus.

APPARATUS:

Cylindrical container, Vee-Bee apparatus (consisting of vibrating table, slump cone), Standard tamping rod, stop watch and trowels.

INTRODUCTION:

Vee-bee test carries out the relative effort measurement to change the mass of the concrete from a definite shape to the other. That is, as per the test, from the conical shape to the cylindrical shape by undergoing vibration process. The measurement of the effort is done by time measurement in seconds. The amount of work measured in seconds is called as the remoulding effort. The time required for the complete remoulding is a measure of the workability and is expressed in the Vee-Bee seconds. The experiment is named after the developer V Bahrmer of Sweden. The method can be also applied for dry concrete. For concrete that have slump value more than 50mm, the remoulding activity will be so fast that the measurement of time is not possible.



PROCEDURE:

1. Initially the sheet metal slump cone is placed inside the cylinder container that is placed in the consistometer. The cone is filled with four layers of concrete. Each concrete layer is one fourth the height of the cone. Each layer after pouring is subjected to twenty-five tamping with the standard tamping rod. The tamping is done with the rounded end of the rod. The strokes are distributed in uniform manner.

- 2. This must be done in such a way theta the strokes conducted for the second and the subsequent layers of concrete must penetrate the bottom layers. Once the final layer has been placed and compacted, the concrete is struck off to make it in level with the help of a trowel. This makes the cone to be exactly filled.
- 3. After the preparation of the concrete cone, the glass disc attached to the swivel arm is moved and is placed on the top of the slump cone placed inside the cylindrical container. The glass disc has to be placed such that it touches the top of the concrete level and the reading is measured from the graduated rod.
- 4. Now the cylindrical cone is removed immediately by raising the cone slowly in the vertical direction. The transparent disc on the top of the concrete is placed down to the new position and the reading is determined.
- 5. The difference in the values measured from step 3 and step 4 will give the slump.
- 6. Now the electrical vibrator is switched on and at the same time we have to start the stop watch. The concrete is allowed to spread out in the cylindrical container. Until the concrete is remolded the vibration is continued. This stage is when the surface of the concrete becomes horizontal and the concrete surface completely adheres uniformly to the transparent disc.
- 7. The time required for complete remoulding in seconds is recorded. This time in seconds gives us the measure of workability of the fresh concrete. This time is expressed in Vee-Bee seconds.

OBSERVATION AND CALCULATIONS:

- 1. Initial reading from the graduated rod, before unmoulding (a) in mm
- 2. The final reading on the graduated rod after removing the mould (b) in mm
- 3. Slump = a b in mm
- 4. The time required for complete remoulding in seconds

RESULT:

Hence the consistency of the concrete is measured in ______ vee-bee seconds.

STANDARD VALUES:

WORKABILITY DESCRIPTION	VEE – BEE TIME (IN SECONDS)
Extremely dry	32 – 18
Very stiff	18 – 10
Stiff	10 – 5
Stiff plastic	5 – 3
Plastic	3 – 0
Flowing	

VIVA:

37.

_____ is practical in field test.

1. What is Vee - Bee test? 2. State the importance of the test conducting? 3. What are the dimensions of the slump cone? 4. Who is the developer of this experiment? 5. What is the vee - bee time for extremely dry workability? What is the standard value of vee – bee time for stiff plastic workability? 6. 7. Workability Means? 8. What is Segregation of concrete? What is Concrete Maturity? 9. How is aggregate impact value expressed? 10. 11. Mix proportions of M30 grade concrete? 12. What is meant by flakiness index? 13. What is the limitations of this test? 14. Size of cube used for testing of Compression Strength of Cement? 15. Plasticizers are used for? 16. List out some of Admixtures available in market? 17. Explain about the influence of W/C ratio? 18. Nominal Mix vs Design Mix? 19. Density of Concrete? 20. What is bleeding of concrete? 21. What do you mean by workability? Workability of concrete can be improved by addition ______. 22. 23. Workability of concrete can be improved by ______. 24. Workability of concrete can be improved by _____. Workability of concrete is directly proportional to ______. 25. 26. Workability of concrete is inversely proportional to . . 27. If compaction factor of concrete is .90, then workability is 28. A compaction factor of .85 for a cement concrete sample indicates _____ 29. Adding water increases 30. Why Shape and texture of aggregates is must? 31. What are the factors effect the workability of concrete? 32. How many types of tests are there to find workability? 33. Workability of concrete is measured by 34. Which test gives good results for rich mixes? Which test used for low workable concretes? 35. 36. Which test Used for high workable concretes?

 What is the Vee-Bee time for medium degree of workability Workability can be resolved Which test gives good results for rich mixes? Which test used for low workable concretes? Which test Used for high workable concretes? Which test used for fiber reinforced concrete? is practical in field test. What is the compaction factor for medium degree of workability What is the Vee-Bee time for medium degree of workability The water-cement ratio is the ratio of 		ne Vee-Bee time for medium degree of work	
 Which test gives good results for rich mixes? Which test used for low workable concretes? Which test Used for high workable concretes? Which test used for fiber reinforced concrete? is practical in field test. What is the compaction factor for medium degree of workable. What is the Vee-Bee time for medium degree of workable. 		io voo zoo unino ioi iniounum degroe ei wein	ability?
 Which test used for low workable concretes? Which test Used for high workable concretes? Which test used for fiber reinforced concrete? is practical in field test. What is the compaction factor for medium degree of workable. What is the Vee-Bee time for medium degree of workable. 	bi	ity can be resolved	
 Which test Used for high workable concretes? Which test used for fiber reinforced concrete? is practical in field test. What is the compaction factor for medium degree of workable. What is the Vee-Bee time for medium degree of workability 	te	st gives good results for rich mixes?	
 Which test used for fiber reinforced concrete? is practical in field test. What is the compaction factor for medium degree of workab What is the Vee-Bee time for medium degree of workability 	te	st used for low workable concretes?	
 45 is practical in field test. 46. What is the compaction factor for medium degree of workab 47. What is the Vee-Bee time for medium degree of workability 	te	st Used for high workable concretes?	
What is the compaction factor for medium degree of workab 47. What is the Vee-Bee time for medium degree of workability	te	st used for fiber reinforced concrete?	
47. What is the Vee-Bee time for medium degree of workability		is practical in field test.	
	s t	ne compaction factor for medium degree of	workability
48. The water–cement ratio is the ratio of	s t	ne Vee-Bee time for medium degree of work	cability?
	ıte	r–cement ratio is the ratio of	
49. A lower ratio leads to	r	atio leads to	
50. How to improve the workability of concrete?	i	nprove the workability of concrete?	

12A. FLOW TABLE TEST

AIM:

To determine the workability of freshly mixed concrete by using of Vee – Bee consistometer apparatus.

APPARATUS:

Cylindrical container, Vee-Bee apparatus (consisting of vibrating table, slump cone), Standard tamping rod, stop watch and trowels.

INTRODUCTION:

As well as getting an accurate measurement of the workability of the concrete, the flow test gives an indication of the cohesion. A mix that is prone to segregation will produce a non-circular pool of concrete. Cement paste may be seen separating from the aggregate. If the mix is prone to bleeding, a ring of clear water may form after a few minutes.

PROCEDURE:

- 1. Before commencing test, the table top and inside of the mould is to be wetted and cleaned of all gritty material and the excess water is to be removed with a rubber squeezer.
- 2. The mould is to be firmly held on the centre of the table and filled with concrete in two layers, each approximately one-half the volume of the mould and rodded with 25 strokes with a tamping rod, in a uniform manner over the cross section of the mould.
- 3. After the top layer has been rodded, the surface of the concrete is to be struck off with a trowel so that the mould is exactly filled.
- 4. The mould is then removed from the concrete by a steady upward pull.
- 5. The table is then raised and dropped from a height of 12.5 mm, 15 times in about 15 seconds.
- 6. The diameter of the spread concrete is the average of six symmetrically distributed calliper measurements read to the nearest 5 mm.



CALCULATION:

The flow of the concrete is the percentage increase in diameter of spread concrete over the base diameter of the moulded concrete, calculated from the following formula.

Flow(%) =
$$\frac{\text{Spread dia.(cm)} - 25}{25} \times 100$$


PF	CI	T	7	٦.
	ľ	UJ		

The flow measured is ______ percentage.

V	T	V	٨		
v	1	v	$\boldsymbol{\Gamma}$	•	

	•
1.	What are the factors influencing the choice of mix proportions?
	State the importance of the experiment?
3.	What is the role of water in fresh concrete?
4.	Describe the field method for assessing the workability.
	Explain the significance of w/c ratio.
	Discuss the factors affecting workability of concrete.
	Explain any two tests for determining the workability of concrete?
	How to calculate the percentage of flow?
	What are the precautions to be taken while conducting the experiment?
	. What is flow table?
11	. What is segregation of concrete?
	. What is bleeding of concrete?
	. What is the height of raising and dropping of the table?
	. What are the dimensions of the table?
15	. How many strokes to be given with the tampering rod in the mould?
16	. Name the apparatus for this experiment?
17	. Flow table test determines the of concrete.
	. The water–cement ratio is the ratio of
19	. A lower ratio leads to
20	. A lower ratio leads to
	is practical in field test.
22	. What is the compaction factor for medium degree of workability?
23	. What is the Vee-Bee time for medium degree of workability?
	. What is concrete maturity?
25	. Maturity methods provide a simple approach for strength of concrete.
26	. The maturity method is a approach to predict the early age strength gain of concrete.
	. Maturity concept is a method.
28	. It the quantity and cost of sampling and testing
	What does x ³ in power's experiment stands for?
	. A lower ratio leads to
	. The material used for UHPC provides compressive strengths up to
32	. "Where the matrix is extremely dense, a weak aggregate may become the weak". Is this statement
	(TRUE / FALSE)?
	. What is the compaction factor for medium degree of workability?
	. It is strength and permeability.
	. "High Performance concrete works out to be economical". Is it true or false?
	. "HPC is not used in high span bridges". Is it true or false?
	. Concrete having 28- days' compressive strength in the range of 60 to 100 MPa.
	. Concrete having 28-days compressive strength in the range of 100 to 150 MPa.
39	. High-Performance Concrete is as compared to Normal Strength Concrete.
40	. The choice of cement for high-strength concrete should not be based only on mortar-cube tests but it
11	should also include tests of compressive strengths of concrete at days.
41	. For high-strength concrete, a cement should produce a minimum 7-days mortar-cube strength of
42	approximately MPa.
42	mm nominal maximum size aggregates gives optimum strength.

. What could be the possible answer among the following for compressive strength of high strength concrete? New that could be the possible answer among the following for water cement ratio for high strength concrete? Due to low w/c ratio Which type of aggregates are used to produce 70MPa compressive strength? Maximum size of aggregates are used to produce 100MPa compressive strength is Maximum size of aggregates are used to produce 100MPa compressive strength is "In bridges, HSC is used". Is it (TRUS / FALSE)?		
concrete? 5. What could be the possible answer among the following for water cement ratio for high strength concrete? 6. Due to low w/c ratio 7. Which type of aggregates are used to produce 70MPa compressive strength? 8. Maximum size of aggregates are used to produce 70MPa compressive strength is 9. Maximum size of aggregates are used to produce 100MPa compressive strength is		
concrete? 5. Due to low w/c ratio 7. Which type of aggregates are used to produce 70MPa compressive strength? 8. Maximum size of aggregates are used to produce 70MPa compressive strength is 9. Maximum size of aggregates are used to produce 100MPa compressive strength is		e possible answer among the following for compressive strength of high strength
5. Due to low w/c ratio 7. Which type of aggregates are used to produce 70MPa compressive strength? 8. Maximum size of aggregates are used to produce 70MPa compressive strength is 9. Maximum size of aggregates are used to produce 100MPa compressive strength is		e possible answer among the following for water cement ratio for high strength
Which type of aggregates are used to produce 70MPa compressive strength? Maximum size of aggregates are used to produce 70MPa compressive strength is Maximum size of aggregates are used to produce 100MPa compressive strength is		atio
. Maximum size of aggregates are used to produce 100MPa compressive strength is	7. Which type of ag	gregates are used to produce 70MPa compressive strength?
. "In bridges, HSC is used". Is it (TRUS / FALSE)?		
	0. "In bridges, HSC	C is used". Is it (TRUS / FALSE)?



13A. SLUMP CONE TEST

AIM:

The slump flow test is used to determine assess the horizontal free flow of self-compacting concrete in the absence of obstructions.

APPARATUS:

- 1. Mould in the shape of a truncated cone with the internal dimensions 200 mm diameter at the base, 100mm diameter at the top and a height of 300 mm.
- 2. Base plate of a stiff non-absorbing material, at least 700mm square, marked with a circle
- 3. marking the central location for the slump cone, and a further concentric circle of 500mm diameter
- 4. Trowel
- 5. Scoop
- 6. Ruler
- 7. Stopwatch(optional).

- 1. About 6 litres of concrete is needed to perform the test, sampled normally. Moisten the base plate and inside of slump cone, place base plate on level stable ground and the slump cone centrally on the base plate and hold down firmly.
- 2. Fill the cone with the scoop. Do not tamp, simply strike off the concrete level with the top of the cone with the trowel.
- 3. Remove any surplus concrete from around the base of the cone. Raise the cone vertically and allow the concrete to flow out freely.
- 4. Simultaneously, start the stopwatch and record the time taken for the concrete to reach the 00mm spread circle (This is the T50 time). floatable test, might be appropriate.
- 5. The T50 time is secondary indication of flow. A lower time indicates greater flow ability. The Brite EuRam research suggested that a time of 3-7 seconds is acceptable for civil engineering applications, and 2-5 seconds for housing applications.
- 6. In case of severe segregation most coarse aggregate will remain in the centre of the pool of concrete and mortar and cement paste at the concrete periphery. In case of minor segregation, a border of mortar without coarse aggregate can occur at the edge of the pool of concrete. If none of these phenomena appear it is no assurance that segregation will not occur since this is a time related aspect that can occur after a longer period.

RESULT:	
Slump for the given sample =	mm

VIVA:

1.	A slump of 50-100mm can be used for
2.	Concrete is filled in how many layers in slump cone in slump test
3.	How many hoppers are there in compaction factor test?
4.	What is the standard w/c value for nominal mix of concrete?
5.	Slump value required for RCC Slab?
6.	What is true slump?
7.	Size of Concrete Cubes?
8.	What are the dimensions of the slump cone?
9.	List out workability tests?
10.	How many strokes for each layer?
11.	What is the slump value for low workability?
12.	Slump value 100 – 175mm indicates workability.
13.	What is zero slump?
14.	What is collapsed slump?
15.	What is shear slump?
16.	What is segregation of concrete?
17.	
18.	What is the slump value for medium workability?
19.	What is the slump value in inch for higher workability?
20.	High strength concrete is defined purely on the basis
21.	Use of HSC in column
	Ultra-High Performance Concrete (UHPC), also known as
23.	The material used for UHPC provides compressive strengths up to
24.	The material used for UHPC provides flexural strengths up to
	Range of modulus of elasticity for UHPC
	What is the compressive strength for UHPC?
	"Where the matrix is extremely dense, a weak aggregate may become the weak". Is this statement true or false?
	What is the percentage of water by weight in UHPC?
	What is the percentage of PC by weight in UHPC?
	What is the percentage of steel fibre by weight in UHPC?
	What is the percentage of accelerator by weight in UHPC?
	Creep is
	If creep effect is considered at a given load, the modulus determined is referred to as
	If θ is creep coefficient then what is E_{long} ?
	Concrete exhibits initial elastic strain which depends on
	This strain increases over time due to
	If the stress is removed, the specimen shows an instantaneous recovery strain the elastic strain on loading.
	According to Lamond and Pielert, it's the that exhibits creep upon application of load on a concrete specimen.
	When concrete is loaded it experiences a large strain upon loading known as
	Aggregate has therefore a direct effect on the long-term deformations of concrete because
	Creep as the age of application of load
	The the aggregate, the is the magnitude of creep.
	The the modulus of elasticity the is the creep.
	A paste structure undergoes creep.
	Creep is to the strength of concrete.
	The rate of creep rapidly with time.
	Aggregates with moisture movement and elastic modulus cause a amount of creep.
	The rate of creep generally with the of the size of aggregates.
	What is elastic strains?
50.	Static modulus of elasticity of concrete has been related to its

14A. V - FUNNEL TEST

AIM:


The described V-funnel test is used to determine the filling ability (flowability) of the concrete with a maximum aggregate size of 20mm.

APPARATUS:

V-funnel, Bucket (±12 litre), Trowel, Scoop, Stopwatch.

INTRODUCTION:

Though the test is designed to measure flowability, the result is affected by concrete properties other than flow. The inverted cone shape will cause any liability of the concrete to block to be reflected in the result if, for example there is too much coarse aggregate. High flow time can also be associated with low deformability due to a high paste viscosity, and with high inter-particle friction. While the apparatus is simple, the effect of the angle of the funnel and the wall effect on the flow of concrete is not clear.



- 1. About 12 litres of concrete is needed to perform the test, sampled normally. Set the V-funnel on firm ground. Moisten the inside surface of the funnel. Keep the trapdoor to allow any surplus water to drain. Close the trap door and place a bucket underneath.
- 2. Fill the apparatus completely with the concrete without compacting or tamping; simply strike off the concrete level with the top with the trowel.
- 3. Open within 10 secs after filling the trap door and allow the concrete to flow out under gravity. Start the stopwatch when the trap door is opened, and record the time for the complete discharge (the flow time). This is taken to be when light is seen from above through the funnel. The whole test has to be performed within 5 minutes.
- 4. Do not clean or moisten the inside surface of the funnel gain. Close the trapdoor and refill the V-funnel immediately after measuring the flow time. Place a bucket underneath.
- 5. Fill the apparatus completely with concrete without compacting or tapping, simply strike off the concrete level with the top with the trowel.

6. Open the trapdoor 5 minutes after the second fill of the funnel and allow the concrete to flow out under gravity.7. Simultaneously start the stopwatch when the trap door is opened and record the time discharge to complete flow (the flow time at T5 minutes). This is to be taken when light is seen from above through the funnel.					
	seconds is considered appropriate.				
RESULT:					
The time of flow	seconds.				

VIVA

VA				
1.	What is the aim of conducting V – Funnel test?			
	What is the amount of concrete is required for this experiment?			
	What is the Vee-Bee time for medium degree of workability?			
	Which test used for fibre reinforced concrete?			
	What are the precautions to be taken?			
	What should be the flow time for self-compacting concrete?			
	A compaction factor of .85 for a cement concrete sample indicates			
	How many types of tests are there to find workability?			
	What are the factors influencing the choice of mix proportions?			
	State the importance of the experiment?			
	What is the role of water in fresh concrete?			
12.	Describe the field method for assessing the workability.			
	Explain the significance of w/c ratio.			
	Discuss the factors affecting workability of concrete.			
	Explain any two tests for determining the workability of concrete?			
	How to calculate the percentage of flow?			
	Slump value required for RCC Slab?			
	What is the limitations of this test?			
19.	Size of cube used for testing of Compression Strength of Cement?			
	Plasticizers are used for?			
21.	A slump of 50-100mm can be used for			
22.	Concrete is filled in how many layers in slump cone in slump test			
23.	How many hoppers are there in compaction factor test?			
24.	What is the standard w/c value for nominal mix of concrete?			
25.	Slump value required for RCC Slab?			
26.	What is true slump?			
27.	Size of Concrete Cubes?			
28.	What are the dimensions of the slump cone?			
29.	List out workability tests?			
30.	How many strokes for each layer?			
31.	What is the slump value for low workability?			
32.	Slump value 100 – 175mm indicates workability.			
33.	What is zero slump?			
	What is collapsed slump?			
35.	What is shear slump?			
36.	What is segregation of concrete?			
37.				
	What is the slump value for medium workability?			
	What is the slump value in inch for higher workability?			
40.	High strength concrete is defined purely on the basis			
41.	For high-strength concrete, a cement should produce a minimum 7-days mortar-cube strength of approximately MPa.			

2	mm nominal maximum size aggregates gives optimum strength.
3. Due to	ow w/c ratio
concrete	
concrete	
	ow w/c ratio
7. Which t	ype of aggregates are used to produce 70MPa compressive strength?
3. Maximi	im size of aggregates are used to produce 70MPa compressive strength is
	m size of aggregates are used to produce 100MPa compressive strength is
). "In brid	ges, HSC is used". Is it (TRUS / FALSE)?

15A. L - BOX TEST

AIM:

To determine the workability or consistency of concrete mix.

APPARATUS:

L box of a stiff non-absorbing material, Trowel, Scoop, Stopwatch.


INTRODUCTION:

This test for self-compacting concrete is based on a Japanese design for underwater concrete, has been described by Peterson. The test assesses the flow of the concrete and also the extent to which it is subjected to blocking by reinforcement. The apparatus consists of rectangular section box in the shape of an "L", with a vertical and horizontal section, separated by a movable gate, in front of which vertical length of reinforcement bar are fitted. The vertical section is filled with concrete, and then the gate lifted to let the concrete flow into the horizontal section.

When the flow has stopped, the height of the concrete at the end of the horizontal section is expressed as a proportion of that remaining in the vertical section. It indicates the slope of the concrete when at rest. This is an indication passing ability, or the degree to which the passage of concrete through the bars is restricted.

The horizontal section of the box can be marked at 200mm and 400mm from the gate and the times taken to reach these points measured. These are known as the T20 and T40 times and are an indication for the filling ability.

The section of bar con be of different diameters and are spaced at different intervals, in accordance with normal reinforcement considerations, 3x the maximum aggregate size might be appropriate. The bar can principally be set at any spacing to impose a more or less severe test of the passing ability of the concrete.



PROCEDURE:

1. bout 14 litres of concrete needed to perform the test, sampled normally. Set the apparatus level on firm

ground, ensure that the sliding gate can open freely and then close it.


- 2. Moisten the inside surface of the apparatus, remove any surplus water, fill the vertical section of the apparatus with the concrete sample.
- 3. Leave it stand for 1 minute. Lift the sliding gate and allow the concrete to flow out into the horizontal section. Simultaneously, start the stopwatch and record the time for the concrete to reach the concrete 200 and 400 marks.
- 4. When the concrete stops flowing, the distances "H1" and "H2" are measured. Calculate H2/H1, the blocking ratio. The whole has tom performed within 5 minutes.

RESULT:

- 1. If the concrete flows as freely as water, at rest it will be horizontal, so H2/H1=1.
- 2. Therefore, the nearest this test value, the "blocking ratio", is unity, the better the flow of concrete.
- 3. The EU research team suggested a minimum acceptable value of 0.8. T20 and T40 time can give some indication of ease of flow, but no suitable values have been generally agreed. Obvious blocking of coarse aggregate behind the reinforcement bars can be detected visually.

VIVA:	
1.	What is the aim of the experiment?
2.	What are the limitations of the experiment?
3.	What is the significance of conducting the experiment?
4.	Workability can be resolved
5.	How to improve the workability of concrete?
6.	What is workability?
7.	What is workability?
8.	List the tests for workability of concrete?
9.	What are the dimensions of the $L - Box$?
10.	What type of concrete need this test?
11.	How much amount of concrete is required for this test?
12.	What is blocking ratio?
13.	For which grade of concrete this experiment is suitable?
14.	Mention the size of coarse aggregate to be used?
15.	Is robo sand is suitable for the mix (True / false).
16.	The water should be free from salts and alkalies (True / False).
17.	What is the size of fine aggregate to be used?
18.	Mention the size of reinforcing bars?
19.	How many bars to be provided in the L - Box?
20.	What is the width of the $L - Box$?
21.	What is plastic shrinkage?
22.	How many types of shrinkages, caused due to cooling and carbonation?
23.	What is drying shrinkage?
24.	What is autogenous shrinkage?
25.	What is carbonation shrinkage?
26.	ACI 305.R.91 specifies Evaporation rate kg/hr/m ² should be avoided to prevent plastic
cracking.	
27.	Carbonic Acid + Ca(OH) ₂ \Rightarrow X. What is the main compound in X?
28.	If there is continuous supply of H ₂ O to the concrete during hydration, concrete expands due to
absorption	of water by the cement gel. Is it (TRU / FALSE)?
29.	Reduction in the volume due to shrinkage causes
30.	It is observed that 14-34% of the 20 years shrinkage occurs in
a) 2 weeks	S
31.	It is observed that 40-80% of the 20 years shrinkage occurs in
32.	It is observed that 66-85% of the 20 years shrinkage occurs in
33.	"If the concrete is placed in 100% relative humidity for a length of time then there WON'T be
any shrink	rage". Is it true or false?
34.	The magnitude of autogenous shrinkage is
35.	Which aggregates have high shrinkage?
36.	Which aggregates have low shrinkage?
37.	The addition of a pozzolanic admixture such as fly ash reduces the

38.	Lowering of might also help, since this would reduce the amount of CH that
forms.	
39.	When the content is low, most ettringite will be formed in the plastic state.
40.	The philosophy of prescribing low cement to improve resistance to sulphate
attack.	
41.	The quality of concrete, specifically a permeability, is the best protection
against su	lphate attack.
42.	For concrete exposed to a very aggressive environment the w/c should be lower than
43.	The quality of concrete, specifically a w/c ratio, is the best protection against
sulphate a	
44.	The quality of concrete, specifically a cement content, is the best protection
against su	lphate attack.
45.	Concentration of water-soluble sulphates in water ppm for mild exposure.
46.	Concentration of water-soluble sulphates in water ppm for severe exposure.
47.	Which test used for low workable concretes?
48.	is practical in field test.
49.	What is the Vee-Bee time for medium degree of workability?
50.	What is the compaction factor for medium degree of workability?



16A. COMPRESSION TEST ON CUBES AND CYLINDERS

AIM:

To determine the compressive strength of cubes and cylinders.

APPARATUS:

Moulds (cylinder mould of 150mm diameter and 300mm height, cube mould of 150mm X 150mm X 150mm), balance, compression testing m/c, mechanical vibrator etc.

INTRODUCTION:

Compressive strength of concrete depends on many factors such as water-cement ratio, cement strength, quality of concrete material, quality control during production of concrete etc.

Test for compressive strength is carried out either on cube or cylinder. Concrete is strong in compression and weak in tension.

PROCEDURE:

MIXING OF CONCRETE FOR CUBE TEST:

Mix the concrete either by hand or in a laboratory batch mixer.

HAND MIXING:

- 1. Mix the cement and fine aggregate on a water tight none-absorbent platform until the mixture is thoroughly blended and is of uniform colour
- 2. Add the coarse aggregate and mix with cement and fine aggregate until the coarse aggregate is uniformly distributed throughout the batch
- 3. Add water and mix it until the concrete appears to be homogeneous and of the desired consistency.

SAMPLING OF CUBES FOR TEST:

- 1. Clean the mounds and apply oil
- 2. Fill the concrete in the moulds in layers approximately 5cm thick
- 3. Compact each layer with not less than 35strokes per layer using a tamping rod (steel bar 16mm diameter and 60cm long, bullet pointed at lower end)
- 4. Level the top surface and smoothen it with a trowel.

PRECAUTIONS FOR TESTS:

The water for curing should be tested every 7 days and the temperature of water must be at $27+-2^{\circ}$ C.

PROCEDURE FOR CUBE TEST:

- 1. Remove the specimen from water after specified curing time and wipe out excess water from the surface.
- 2. Take the dimension of the specimen to the nearest 0.2m
- 3. Clean the bearing surface of the testing machine
- 4. Place the specimen in the machine in such a manner that the load shall be applied to the opposite sides of the cube cast.
- 5. Align the specimen centrally on the base plate of the machine.
- 6. Rotate the movable portion gently by hand so that it touches the top surface of the specimen.
- 7. Apply the load gradually without shock and continuously at the rate of 140 kg/cm²/minute till the specimen fails
- 8. Record the maximum load and note any unusual features in the type of failure.

PROCEDURE FOR CYLINDER TEST:

- 1. Cast the cylinder and cure for 28 days.
- 2. Takeout the specimen from the curing tank.
- 3. Wipe out the excess water from the surface of specimen.
- 4. Place the specimen vertically on the platform of compression testing machine.
- 5. Apply the load continuously and uniformly without shock at the rate of 315 kn/min. And continue the loading until the specimen fails.
- 6. Record the maximum load taken.

S.NO	DAYS AFTER CASTING	STRENGTH GAIN %
1	1 DAYS	16
2	3 DAYS	40
3	7 DAYS	65
4	14 DAYS	90
5	28 DAYS	99

COMPRESSIVE STRENGTH OF DIFFERENT GRADES OF CONCRETE AT 7 AND 28 DAYS:

GRADE OF CONCRETE	MINIMUM COMPRESSIVE STRENGTH N/MM ² AT 7 DAYS	SPECIFIED CHARACTERISTIC COMPRESSIVE STRENGTH (N/MM²) AT 28 DAYS
M 15	10	15
M 20	13.5	20
M 25	17	25
M 30	20	30
M 35	23.5	35
M 40	27	40

ORSERVATIO	N	•
------------	---	---

Dimension of the cube: 150mm X 150mm X 150mm

S.	Compressive strength of cement = (Load at failure)/ (Cross- Sectional
NO	area)
1	
2	
2	
3	

CALCULATION FOR CUBE TESTING:

Size of the cube = 15 cm x 15 cm x	15cm		
Area of the specimen (calculated	from the mean size of the	e specimen)=225	5 cm^2 .
Characteristic compressive streng	$gth(f_{ck})at 7 days = $	·	
Expected maximum load =f _{ck} x a	rea x f.s		
Range to be selected is	·		
Similar calculation should be do	ne for 28 days compressiv	e strength	
Maximum load applied =	tones =	N.	
Compressive strength = (Load in	N/ Area in mm ²)=	1	N/mm^2 .
CALCULATIONS FOR CYLE Range Calculation Characteristic compressive strent Area of cross section = pi X d ² Expected load = stress x area xf	$agth at 28 days = N/mm^2$		
Range to be selected is			
RESULT:			
Average compressive strength o	f the concrete cube =	N/	mm ² (at 7 days)
Average compressive strength o	f the concrete cube =	N/mm	² (at 28 days).

Average compressive strength of the concrete cylinder = $\underline{\hspace{1cm}}$ N/ mm² (at 7 days)

Average compressive strength of the concrete cylinder = ______ N/mm² (at 28 days).

EXAMPLE:

Compressive Strength of Concrete Cubes& cylinders- Lab Test & Procedure

PROCEDURE:

CUBE CASTING:

- 1. Measure the dry proportion of ingredients (Cement, Sand & Coarse Aggregate) as per the design requirements. The Ingredients should be sufficient enough to cast test cubes.
 - 2. Thoroughly mix the dry ingredients to obtain the uniform mixture.
- 3. Add design quantity of water to the dry proportion (water-cement ratio) and mix well to obtain uniform texture.
 - 4. Fill the concrete to the mould with the help of vibrator for thorough compaction.
- 5. Finish the top of the concrete by trowel & tapped well till the cement slurry comes to the top of the cubes.

CURING:

- 1. After some time, the mould should be covered with red gunny bag and put undisturbed for 24 hours at a temperature of 27 $^{\circ}$ Celsius \pm 2.
 - 2. After 24 hours remove the specimen from the mould.
- 3. Keep the specimen submerged under fresh water at 27 $^{\circ}$ Celsius. The specimen should be kept for 7 or 28 days. Every 7 days the water should be renewed.
 - 4. The specimen should be removed from the water 30 minutes prior to the testing.
 - 5. The specimen should be in dry condition before conducting the testing.
 - 6. The Cube weight should not be less than 8.1 Kgs

TESTING:

- 1. Now place the concrete cubes into the testing machine. (centrally).
- 2. The cubes should be placed correctly on the machine plate (check the circle marks on the machine). Carefully align the specimen with the spherically seated plate.
 - 3. The load will be applied to the specimen axially.
 - 4. Now slowly apply the load at the rate of 140kg/cm2 per minute till the cube collapse.
 - 5. The maximum load at which the specimen breaks is taken as a compressive load.

CALCULATION:

Compressive Strength of concrete = Maximum compressive load / Cross Sectional Area

VA:	
	In Charpy test specimen, the angle of v-notch section is
	For hardness test of copper in Brinell hardness tester, the diameter of ball is
3.	During compression test of cast iron, the failure occurs i.e. the crack appears along th
4.	The property of a material that resists penetration or indentation by means of abrasion or scratching is known as
5.	The indenter used in Brinell hardness test is a
	The ability of the material to resist stress without failure is called
	"The shape of specimen used in compression test is Cube and cylinder"
8.	Equipment used to test Compression Strength of Concrete?
9.	Size of Concrete Cubes?
10.	No. of Cube samples required for testing Compression Strength for 100 m3 of concrete?
11.	List the various methods of compacting of concrete?
12.	How is compressive strength of concrete is measured?
13.	What should be the compressive strength of concrete at 7 days?
14.	What is F_{ck} of concrete?
15.	What is the compressive strength of M_{30} grade concrete?
16.	How long does it take to concrete to reach its full strength?
17.	What should be the compressive strength of concrete at 14 days?
18.	What should be the compressive strength of concrete at 28 days?
19.	What is standard deviation for M_{40} grade?
20.	What happens if we test a wet cube in a compressive strength test machine?
21.	Tensile test can be performed on
22.	Which machine records the change in length of specimen?
23.	The ability of the material to resist stress without failure is called
24.	In universal testing machine, for a circular section specimen, the gauge length is taken to be
25.	"The shape of specimen used in compression test is Cube and cylinder".
26.	During compression test of cast iron, the failure occurs i.e. the crack appears along the
27.	The property of a material that resists penetration or indentation by means of abrasion or scratching known as
	The indenter used in Brinell hardness test is a
29.	For hardness test of copper in Brinell hardness tester, the diameter of ball is
	In charpy test specimen, the angle of v-notch section is
31.	The breaking up of cohesion in a mass of concrete is called
32.	The separation of water or water-cement mixture from the freshly mixed concrete is known bleeding.
33.	The continuous strain, which the concrete undergoes due to application of external loads, is called
34	Harshness in concrete is due to the excess of
	In order to avoid segregation, the concrete should not be thrown from a height (TRUE / FALSE)
	Reinforced cement concrete is equally strong in taking
	Plain cement concrete is strong in taking

39. What is internal sulphates attack?
40. What is internal sulphates attack?
41. What is flexural strength?
42. What is equivalent flexural load?
43. What is equivalent flexural strength?
44. What is equivalent flexural strength ratio?
45. Calipers, capable of reading the dimensions of test specimens to an accuracy of 46. Rule (ruler/scale), capable of reading the dimensions of test specimens to an accuracy of
47. Load measuring device shall be capable of measuring loads to an accuracy of
48. The tolerances on the cross-section of the test specimens shall be within ±
49. The flexural strength (or modulus of rupture) is obtained for the first peak load, Pmax
as:
50. A data acquisition system capable of digitally recording and storing load and deflection data at least


17A. FLEXURE TEST

AIM:

To determine the Flexural Strength of Concrete, which comes into play when a road slab with inadequate subgrade support is subjected to wheel loads and / or there are volume changes due to temperature / shrinking.

APPARATUS:

Beam mould of size 15 x 15x 70 cm, Tamping bar, Flexural test machine.



- 1. Prepare the test specimen by filling the concrete into the mould in 3 layers of approximately equal thickness.
- 2. Tamp each layer 35 times using the tamping bar as specified above. Tamping should be distributed uniformly over the entire cross-section of the beam mould and throughout the depth of each layer.
- 3. Clean the bearing surfaces of the supporting and loading rollers, and remove any loose sand or other material from the surfaces of the specimen where they are to make contact with the rollers.
- 4. Circular rollers manufactured out of steel having cross section with diameter 38 mm will be used for providing support and loading points to the specimens. The length of the rollers shall be at least 10 mm more than the width of the test specimen. A total of four rollers shall be used, three out of which shall be capable of rotating along their own axes. The distance between the outer rollers (i.e. span) shall be 3d and the distance between the inner rollers shall be d. The inner rollers shall be equally spaced between the outer rollers, such that the entire system is systematic.
- 5. The specimen stored in water shall be tested immediately on removal from water; whilst they are still wet. The test specimen shall be placed in the machine correctly centred with the longitudinal axis of the specimen at right angles to the rollers. For moulded specimens, the mould filling direction shall be normal to the direction of loading.
- 6. The load shall be applied at a rate of loading of 400 kg/min for the 15.0 cm specimens and at a rate of 180 kg/min for the 10.0 cm specimens.

CALCULATION: The Flexural Strength or modulus of rupture (fb) is given by
$f_b = pl/bd^2 \label{eq:bd2}$ (when a > 20.0cm for 15.0cm specimen or > 13.0cm for 10cm specimen)
or
$f_b = 3pa/bd^2$
(when a < 20.0 cm but > 17.0 for 15.0cm specimen or < 13.3 cm but > 11.0 cm for 10.0cm specimen.)
Where, a = the distance between the line of fracture and the nearer support, measured on the center line of the tensile
side of the specimen
b = width of specimen (cm)
d = failure point depth (cm)
l = supported length (cm) p = max. Load (kg)
$p = \max$. Load (kg)
RESULT: The Flexural strength of the concrete is reported

VIVA	
	What is flexural strength?
	What is equivalent flexural load?
	What is equivalent flexural strength?
	What is equivalent flexural strength ratio?
	Callipers, capable of reading the dimensions of test specimens to an accuracy of
6.	Rule (ruler/scale), capable of reading the dimensions of test specimens to an accuracy of
7.	Load measuring device shall be capable of measuring loads to an accuracy of
8.	The tolerances on the cross-section of the test specimens shall be within \pm
9.	The flexural strength (or modulus of rupture) is obtained for the first peak load, P_{max} as
10.	A data acquisition system capable of digitally recording and storing load and deflection data at least
	Tensile test can be performed on
12.	Which machine records the change in length of specimen?
13.	How the flexural strength is calculated?
14.	What are the precautions to be taken while place the specimen?
15.	What are the standard dimensions of the beam mould?
16.	Differentiate between three-point loading and two-point loading?
17.	Concrete weak in tension and strong in compression (True / False).
18.	What is the aim of the experiment?
19.	What the load to be applied at 15cms?
20.	What is the line of fracture?
21.	What is flexural strength?
22.	What is equivalent flexural load?
23.	What is equivalent flexural strength?
24.	What is equivalent flexural strength ratio?
25.	Calipers, capable of reading the dimensions of test specimens to an accuracy of
26.	Rule (ruler/scale), capable of reading the dimensions of test specimens to an accuracy of
27.	Load measuring device shall be capable of measuring loads to an accuracy of
28.	The tolerances on the cross-section of the test specimens shall be within \pm
29.	The flexural strength (or modulus of rupture) is obtained for the first peak load, Pmax as:
30.	A data acquisition system capable of digitally recording and storing load and deflection data at least
31.	The slump would not exceed 50 mm when compacting concrete with vibrators (TRUE / FALSE).
	When vibrators are used for compaction, the consistency of concrete depends upon the
	The vibrator should not be immersed through a full depth of freshly laid concrete (TRUE / FALSE).
	The levelling operation that removes humps and hollows and give a true, uniform concrete surface is
٠	called
35	The final operation of finishing the concrete surface is called
	The process of removing the irregularities from the surface of concrete left after screeding is called
50.	floating.

8. After the curing of 28 days, the concrete gains strenge. 9. The construction joints in cement concrete 10. For compacting large sections of mass concrete	
O. For compacting large sections of mass concre	
	ete in structures, the type of vibrator used
1. In Charpy test specimen, the angle of v-notch sectio	
2. For hardness test of copper in Brinell hardness teste	
B. During compression test of cast iron, the fai	ilure occurs i.e. the crack appears along th
1. The property of a material that resists penetration of known as	r indentation by means of abrasion or scratching
5. The indenter used in Brinell hardness test is a	
5. The ability of the material to resist stress without fai	lure is called
7. "The shape of specimen used in compression test is	Cube and cylinder"
3. Equipment used to test Compression Strength of Co	
9. Size of Concrete Cubes?	
No. of Cube samples required for testing Compressi	on Strength for 100 m3 of concrete?

18A. SPLITTING TENSILE TEST

AIM:

This method covers the determination of the splitting tensile strength of cylindrical concrete specimens.

APPARATUS:

Compression testing machine, two packing strips of plywood 30 cm long and 12mm wide.



- 1. Take the wet specimen from water after 7 days of curing
- 2. Wipe out water from the surface of specimen
- 3. Draw diametrical lines on the two ends of the specimen to ensure that they are on the same axial place.
- 4. Note the weight and dimension of the specimen.
- 5. Set the compression testing machine for the required range.
- 6. Keep are plywood strip on the lower plate and place the specimen.
- 7. Align the specimen so that the lines marked on the ends are vertical and centred over the bottom plate.
- 8. Place the other plywood strip above the specimen.
- 9. Bring down the upper plate to touch the plywood strip.
- 10. Apply the load continuously without shock at a rate of approximately 1421kg/cm2/minute (Which corresponds to a total load of 9900kg/minute to 14850kg/minute).
- 11. Note down the breaking load(P).

CALCULATIONS:

As per IS456, split tensile strength of concrete. = 0.7fck. The splitting tensile strength is calculated using the formula

Tsp = 2P/piDL

Where P = applied load

D = diameter of the specimen L = length of the specimen

Therefore P = Tsp x pi DL/2Expected load = P x f.s

Split tensile strength T = 2P/pi DL.

RESULT:

Splitting tensile strength of given concrete = _____N/mm².

VIVA:
1. What is the importance of conducting the experiment?
2. What are the precautions to be taken?
3. What is split tensile strength?
4. What are the limitations?
5. What happens if the wet specimen is tested?
6. How the splitting tensile strength is calculated?
7. Differentiate the flexural strength and split tensile strength?
8. What are the standard split tensile strength for the M30 grade of concrete?
9. Differentiate between three-point loading and two-point loading?
10. What are the standard dimensions of the cylinder mould?
11. What is the % of strength when the specimen is testes for 7 days?
12. What is standard deviation?
13. How much load should be applied continuously on the specimen?
14. Load measuring device shall be capable of measuring loads to an accuracy of
15. The flexural strength (or modulus of rupture) is obtained for the first peak load, P max
as
16. A data acquisition system capable of digitally recording and storing load and deflection data at least
·
17. Callipers, capable of reading the dimensions of test specimens to an accuracy of
18. Rule (ruler/scale), capable of reading the dimensions of test specimens to an accuracy of
19. How many strokes to be given for each layer?
20. Why the oil layer is applied to the mould?
21. Generally what is the w/c ratio?
22. The slump would not exceed 50 mm when compacting concrete with vibrators (TRUE / FALSE)
23. The levelling operation that removes humps and hollows and give a true, uniform concrete surface is
called
24. What is the limitation of plasticizers?
25. What is the allowed reduction of water with super plasticizers without reducing workability?
26. A lower ratio leads to
27. Silica fume is
28. Content of SiO ₂ in silica fume?
29. What is the content of Al ₂ O ₃ in fly ash? 30. Find the odd one out.
a) Water reducing plasticizers
b) Water reducing plasticizers
c) High performance plasticizers
d) Super plasticizers
31. Which machine is preferred for abrasion test?
32. A maximum value of percent is allowed for WBM base course in Indian conditions.
33. Aggregates to be used for wearing course, the impact value shouldn't exceed percent.
34. What is the range of water absorption of aggregates used in road?

magr 36. I impa 37. V 38. V 40. V 41. V 43. T 44. T avails 45. L 46. L 47. L 48. V 49. V	nesium sulphate solution. If 60% aggregates doesn't pass through the 2.36 act value? What C31 test under Standard ASTM test method What C39 test under Standard ASTM test method What C138 test under Standard ASTM test method What C143 test under Standard ASTM test method What C172 test under Standard ASTM test method What C173 test under Standard ASTM test method What C173 test under Standard ASTM test method The compressive strength required The adequate workability necessary for lable. water-cement ratio content to give	od? nod? nod? nod? nod? nod? from structural consideration compaction with the compacting equipment e adequate durability for the particular site conditions. cking due to temperature cycle in mass concrete.

19A. MODULUS OF ELASTICITY

AIM:

To determine the modulus of elasticity of concrete.

APPARATUS:

Concrete calendar 15 cm diameter and 30cm long.

PROCEDURE:

- 1. Assemble the top and bottom frame by keeping the spacers in position.
- 2. Keep the pivot rod on the screws and lock them in position.
- 3. Keep the tightening screws of the bottom and top frame unscrewed (but not completely).
- 4. Place the specimen on a level surface.
- 5. Keep the compressometer centrally on the specimen so that the tightening screw of the bottom and top frame are at equal distance from the two ends.
- 6. Tighten the screws so that the compressometer is held on the specimen.
- 7. Remove the spacers by unscrewing the spacer screws.

TESTING:


- 1. Place the specimen with compressometer in the compression testing machine and centre it.
- 2. Apply load continuously without stock at a rate of 140 kg/cm²/minute until a stress of
- 3. $(c+5)kg/cm^2$ is reached where c is the one third of average compressive strength of cubes calculated to the nearest $5kg/cm^2$ (a load of 12.4T)
- 4. Maintain the load at this stress for at least one minute and reduce gradually to an average stress of 1.5 kg/cm²(a load of 0.3 T).
- 5. Apply the load again at the same rate until an average stress of (c+ 1.5) kg/cm² is reached(a load of 11.8T)
- 6. Note the compressometer reading at this load.
- 7. Reduce the load gradually and take readings at an interval of 1T up to 0.3T(11.8T,10.8T,9.8T,8.8T,7.8T,....,1.8T,0.3T)
- 8. Apply load third time and note the compressometer readings at an interval of 1T (0.3T,1.8T,2.8T,.....11.8T).



CALCULATION:

(Take	l tangent modulus e load & deflection from the in ent modulus at working stress e load and deflection from the	=	stress/ strain	; stress)	
	nt modulus = stress/ e load and deflection from the	/strain line join	ing initial point a	nd the point at working	g stresses)
RESU	ULT:				
1.	Initial tangent modulus of giv				
 3. 	Tangent modulus at working Secant modulus (Modulus of	-			_ N / mm²

20 quality construction the western of materials
38 quality construction the wastage of materials.
39. Quality management system improves perception of customers towards company. True or false
40. It opens the area of improvement for quality construction rationally based on the documents from
projects.
41. The property of a material that resists penetration or indentation by means of abrasion or scratching is known
as 42. During compression test of cast iron, the failure occurs i.e. the crack appears along the
43. What is the importance of conducting the experiment?
44. What are the precautions to be taken?
45. What is split tensile strength?
46. What are the limitations?
47. What happens if the wet specimen is tested?
48. How the splitting tensile strength is calculated?
49. Differentiate the flexural strength and split tensile strength?
50. What are the standard split tensile strength for the M30 grade of concrete?
30. What the the standard split tensile strength for the 1430 grade of concrete.



20A. PENETRATION TEST

AIM: To determine grade of given bitumen

APPARATUS:

It consists of items like container, needle, water bath, Penetrometer, stop watch etc. Thefollowing are the standard specifications as per ISI from the above apparatus.

Container:-A flat bottomed cylindrical metallic container 55 mm in diameter 35 mm or 57 mm inheight.

Needle: A straight highly polished cylindrical hard steel needle with conical end having the shape and dimensions as given in figure 7.1. The needle is providing with a shank approximately mm in diameter in to which it is immovably fixed.

Water bath: A water bath is maintained at $25 \pm 1^{\circ}$ C containing not less than 10 liters of water. The simple is immersed to depth not less than 100mm from the top and supported on a perforated shelf not less than 50mm from the bottom of the bath.

Penetrometer: It is an apparatus which allows the needle assembly of gross weight 100g to penetrate without appreciable friction for the desire duration of time. The dial is accurately calibrated to give penetration value in units one tenth of mm.

Transfer tray: A small tray which can keep the container fully immersed in water during the test.

- ➤ The bitumen is softened to a pouring consistency between 75°C and 100°C above the approximate temperature at which bitumen softens. The sample material is thoroughly stirred to make it homogenous and free from air bubbles and water.
- The sample material is then poured in to the container to a depth at least 15 mm more than the expected penetration. The sample containers are cooled in atmosphere of temperature not lower than 13°C for one hour. Then they are placed in temperature controlled water bath at a temperature of 25°C for a period of one hour.
- The sample container is placed in the transfer way with water from the water bath and placed under the needle of the penetrometer. The weight of needle, shaft and additional weight checked. The total weight of this assembly should be 100g.
- ➤ Using the adjusting screw, the needle assembly is lowered and the tip of the needle is made to just touch the top surface of the sample; the needle assembly is clamped in this position. The contact of the tip of the needle is checked using the mirror placed on the rear of the needle. The initial reading of the penetrometer dial is either adjusted to zero or initial reading is taken before releasing the needle. The needle is released exactly for a period of 5.0 s by pressing the knob and the final reading is taken on the dial.

At least three measurements are made on this simple by testing at distance of less than 100 mm apart. The sample container is also transferred in the water bath before next testing done so as to maintain a constant temperature of 25°C. The test is repeated with sample in the other container.

RESULTS:

The difference between the initial and final penetration reading is taken as the penetration value. The mean value of three consistent penetration measurements is reported as the penetration value. It is further specified by ISI that results of each measurement should not vary from the mean value reported above by more than the following:

Penetration grade	Repeatability
0-80	4 percent
80-225	5 percent
Above225	7 percent




Fig 7.1 Penetrometer

Pouring temperature Period of cooling in atmosphere			: :	
Period of cooling in water bath Room temperature			:	
			:	
Ouration of releasing th	he penetr	ration needle	:	
est temperature			:	
Penetrometer reading	dial	Test1	Test2	Test3
Initial				
Final				

Lab-In charge

Date

20B. SOFTENING POINT TEST

AIM: To determine softening point of a given bitumen sample.

APPARATUS:

- > It consists of Ring and Ball apparatus
- > Steel Balls they are two in number. Each as a diameter of 9.5 mm and weight 2.5 to 5 g.
- > Brass Rings there are two rings of the following dimensions.

Depth 6.4 mm

Inside diameter at top 17.5 mm

Inside diameter at bottom 15.9 mm

Outside diameter 20.6 mm

- ➤ Brass rings are also placed with ball guides as shown in fig 8.1
- > Support the metallic support is used for placing pair of rings.
- The upper surface of the rings is adjusted to be 50mm below the surface of the water or liquid contained in the bath. A distance the bottom of the rings on top surface of the bottom plate of support is provided it has housing for a suitable thermometer.
- ➤ Bath and Stirrer: A heat resistance glass container of 85mm dia and 120mm materials having softening point above 80 degree C and glycerin for materials having softening point above 80 degree C. Mechanical stirrer is used for ensuring uniform distribution all times throughout the bath.

- ➤ Sample material is heated to a temperature between 75 and 100°C above the approximate softening point until it is fluid and is poured in heated rings placed on metal plate.
- > To avoid sticking of the bitumen to metal plate coating is done to this with a solution of glycerin and dextrin .After cooling the rings in air for 30 minutes.
- The excess bitumen is trimmed and rings are placed in the support as discussed in item above .At this time the temperature of distilled water is kept at 5°C. This temperature is maintained for 15 minutes after which the balls are placed in position.
- The temperature of water is raised at uniform rate of 5°C per minute with a controlled heating unit the bitumen softens and touches the bottom plate by sinking of balls.
- At least two observations are made. For material whose softening point is above 80°C, glycerin is used as a heating medium and the starting temperature is 35°C, instead of 5°C.

OBSERVATION SHEET

Pouring temperature :

Period of cooling atmosphere :

Period of cooling in water bath : Room temperature :

Rate of heating :

Liquid used in water bath :

Rate of heating :

TIME IN MINTUES	TEMPERATURE IN °C




Fig 9.1 Softening Point Test Concept

RESULTS: The temperature at the instant when each of the ball and sample touches the bottomplate of support is recorded as softening value. The mean of duplicate determinations is noted. It is essential that the mean value of softening point (temperature) does not differ from individual observations by more than the following limits.

Softening point	Repeatability	Reproducibility
Below 30°C	2°C	4°C
30 to 80°C	1°C	2°C
Above 80°C	2°C	4°C

RESULT: The softening point of given bitumen sample is_____

APPLICATIONS OF SOFTENING POINT TEST:

Softening point is essentially the temperature at which the bituminous binders have an equal viscosity. The softening point of tar is therefore related to the equi-viscous temperature. The softening point found by the ring and ball apparatus is approximately 20°C lower than the e.v.t..Softening point, thus gives an idea of the temperature at which the bituminous material attains a certain viscosity. Bitumen with higher softening point may be preferred in the warmer place.

The ranges of softening point specified by the Indian standards Institute for various grades of bitumen are given below.

Table 9.1: Ranges of Softening Point Specified by The Indian Standards Institution for Various Grades of Bitumen

Bitumen grades	Softening point, °C
A 25 & A 35	55 to 70
S 35	50 to 65
A 45,S 45 & A 65	45 to 60
S 65	40 to 55
A 90 & S 90	35 to 50
A 200 & S 200	30 to 45

A' denotes bitumen from Assam petroleum and 'S' denotes bitumen from sources otherthan from Assam petroleum. Also see table under 'Application of Penetration test '.

Lab-In charge
Date

Viva Questions:

- 1. What do you understand by the term repeatability
- 2. What do you understand by the term reproducibility
- 3. Explain the significance of ductility test.
- 4. What do you understand by the term 30/40 bitumen?
- 5. What are the precautions to be taken while conducting a penetration test?
- 6. What are the applications of penetration test?
- 7. How do you determine the softening point of the bitumen?
- 8. What is softening point?

condition of test.

revolutions per minute

26. is the test apparatus for flash and fire test

- 9. If material A has softening point of 56 and B has 42 which binder is good and why?
- 10. Define flash and fire points.
- 11. What is the significance of flash and fire point test?
- 12. What are the parameter that affects the result of flash and fire point tests?
- 13. Briquette mould dimensions are:

14.	Assam petroleum grade are the following
15.	Minimum ductility value, of S 35 iscm.
16.	Penetration test is to determineof given bitumen
17.	The bitumen is softened to a pouring consistency betweenabove the approximate
	temperature at which bitumen softens
18.	The sample containers are cooled in atmosphere of temperature not lowerthan for one
	hour.
19.	Softening point, thus gives an idea of the temperature at which the bituminous material
	attains
20.	with higher softening point may be preferred in the warmer place.
21.	The temperature at the instant when each of the ball and sample touches the bottom plate of
	support is recorded as
22.	To determine softening point of a given bitumen sample_test is done.
23.	Sample material is heated to a temperature between
24.	The flash point is theat which the vapors of substance momentarily takes fire in
	the term of a under specified point test.
25.	The point is the at which the material gets ignited and burns under specified

27. Bitumen materials leave out volatiles at ______depending upon their grades

28. The heating is done _____ per minute the string is done at a rate of approximately 60

21A. DUCTILITY TEST

AIM: To determine ductility of the given bitumen.

THEORY: In the flexible pavement construction where bitumen binders are used, it is of significant importance that the binders from ductile thin films around the aggregates . This serves as a satisfactory binder in improving the physical interlocking of the aggregates . The binder material which does not possess sufficient ductility would crack and thus provide previous pavement surface . This in turn results in damaging effect to the pavement structure. It has been stated by some agencies that the penetration and the type of crude source of the bitumen, sometimes it has been observed that the above statement is incorrect . It may hence be mentioned that the bitumen may satisfy the penetration value, but may fail to satisfy the ductility requirements. Bitumen paving engineer would however want that both test requirements are satisfied in the field jobs. penetration and ductility can not in any case replace each other . The ductility is expressed as the distance in centimeters to which a standard briquette of bitumen can be stretched before the thread breaks . The test is conducted at $27^{-0} \pm 0.5^{0}$ C and a rate of pull of 50 ± 2.5 mm per minute . The test has been standardized by the ISI . The ductility test concept is show in fig 10.1.

APPARATUS: The ductility test apparatus consists of items like sample(briquette)moulds water bath square-end trowel or putty knife sharpened on end and ductility machine .Standard specifications as per ISI being:

(a) Briquette mould: Mould is made of brass metal with shape and dimensions as indicated in fig 8.2. Both ends called clips possess circular holes to grip the fixed and movable ends of the testing machine. Side pieces when placed together from the briquette of the following dimensions:

Length --- 75mm

Distance between clips ---- 30mm

Width at mouth of clips ---- 20mm

Cross section at minimum width ---- 10mm x10mm

(b) Ductility machine: It is an equipment which functions as constant temperature water bath and a pulling device at a pre-calibrated rate .The central rod of the machine is threaded and through a gear system provides movement to one end where the clip is fixed during initial placement .The clips are thus pulled apart horizontally at a uniform speed of 50 ± 2.5 mm per minute .The machine may have provision to fix two or more mould so as to test these specimens simultaneously.

PROCEDURE:

- ➤ The bitumen sample is melted to a temperature of 75°C to 100°C above the approximate softening point until it is fluid .It is strained through IS sieve 30, poured in the mould assembly and placed on a brass plate, after a solution of glycerin and dextrin is applied at all surfaces of the mould exposed to bitumen .Thirty to forty minutes after the sample is poured into the moulds the plate assembly along with the sample is placed in water bath maintained at 27°C for 30 minutes.
- ➤ The sample and mould assembly are removed from water bath excess bitumen is cut if by to level the surface using hot knife .After trimming the specimen, the mould assembly containing sample is replaced in water both maintained at 27°C for 85 to 95 minutes .
- ➤ The sides of the mould are now removed and the clips are carefully booked on the machine without causing any initial strain .Two or more specimens may be prepared in the moulds and clipped to the machine so as to conduct these tests simultaneously.
- The pointer is set to read zero .The machine is started and the two clips are thus pulled apart horizontally .While the test is in operation, it is checked whether the sample is immersed in water at depth of at least 10 min.
- ➤ The distance at which the bitumen thread of each specimen breaks, is recorded (in cm) to report as ductility value.




Fig. 8.1 Ductility Test Concept

The distance stretched by the moving end of the specimen up to recorded as ductility value which is

DISCUSSION:

The ductility value gets seriously affected if any of the following factors are varied:

- (1)Pouring temperature
- (2) Dimensions of briquette
- (3) Improper level of briquette placement
- (4)Rate of pulling

Increase in minimum cross section of 10sq.mm and increase in test temperature would record increased ductility value.

APPLICATIONS OF DUCTILITY TEST:

A certain minimum ductility is necessary for a bitumen binder . This is because of the temperature changes in the bitumen nixes and the repeated deformations that occur in flexible pavements due to the traffic loads . If the bitumen has low ductility value, the bituminous pavement may crack, especially in cold weather . The ductility values of bitumen vary from 5 to over 100.

Several agencies have specified the minimum ductility values for various types of bituminous pavement .Often a minimum value of 50cm is specified for bituminous construction.

Table8.1: the Minimum Ductility values specified by the Indian Standards Institution for Various Grades of Bitumen Available in India

Source of paving bitumen and penetration grade	Minimum ductility value, cm.
Assam petroleum A 25	5
A 35	10
A 45	12
A 65, A90& A 200	15
Bituminous from sources other than Assam petroleum S 35	50
S45, S65,S90	75

OBSERVATION SHEET:

Period of cooling in atmosphere :

Period of cooling in water bath before trimming :

Period of cooling in water bath after trimming :

Dimension	ns of briquette:				
	length				
	 distance between the clip 	os			
	width at mouth of clips				
	 cross section at minimum 	n width			
	BRIQUETE	1	2	3	
	UMBER				
	INITIAL				
	FINAL				
	EAN DUCTILITY VALUE				
	: ne ductility value of given bitumen san	mple is			
		mple is			
RESULT Th		mple is			
		mple is			
		mple is			
		mple is			
		mple is			
		mple is			
		mple is			
Th	ne ductility value of given bitumen san	mple is			
	ne ductility value of given bitumen san	mple is			

21B.ELASTIC RECOVERY OF BITUMEN

This procedure describes the method of measuring recovery of tensile deformation of an asphalt sample by using a standard Ductilometer. The testing procedure uses similar equipment and methods as AASHTO T 51.

AIM: To find out the elastic recovery of bitumen

APPARATUS

•	Duct	ilom	eter	and	rela	ted	equip	meni	t, as	speci	fied	by	AAS	SHT	Т	51.	Ther	e mus	t al	lso	be some	meth	od
ava	ilable	of s	topp	ing	the l	Duc	tilome	eter :	at a	point	in	the	test	and	holo	ding	the s	ample	at	a o	constant	level	of
def	ormati	ion.																					

- Clock or watch, capable of measuring a 5 min. □ 10 sec. and a 1 hr. □ 5 min. period.
- Scissors.

PROCEDURE

- o Prepare the apparatus and the samples as specified in AASHTO T 51, Sections 5.1–5.3.
- o Attach the sample clips to the pins or hooks of the Ductilometer.
- O Begin pulling the clips apart at a rate of 50 mm/min. (2 in./min.)
- When the sample elongation reaches 200 mm (8 in.), stop pulling the clips apart.
- o If the sample breaks before 200 mm (8 in.) elongation, consider the test abnormal and failthe sample after obtaining this result several times.
- \circ Hold the sample at 200 mm (8 in.) elongation for 5 min. \square 10 sec.
- Cut the sample at its approximate center using the scissors. The cut ends of the samplewill begin to draw apart.
- o Allow the sample to relax for 1 hr. \Box 5 min.
- Manually move the sample clips together until the cut ends of the sample meet.
- Record the elongation in mm (in.) indicated by the Ductilometer when the cut ends of the sample are touching.
- o Calculate the elastic recovery using the equation shown in equation below.

CALCULATIONS

Calculate the elastic recovery as a percentage of the total elongation recovered by the sample during the test:

$R = \frac{200 - E_f}{200} \times 100$)%			
Where				
	e elastic recovery se final elongation record	led		
	stic recovery of bitumen			

21C.VISCOSITY OF BITUMEN

It is defined as fluid property of the material as resistance to flow.

<u>AIM:</u> To determine the viscosity of bitumen by tar viscometer as per **IS: 1206 (Part 2)**

APPARATUS: Tar viscometer, cup, valve, receiver, thermometer etc.

PROCEDURE:

Preparation of the Sample – Heat the sample to a temperature not more than 60° C for the tars and pitches and not more than 90° C for bitumen's above their respective approximate softening point temperature respectively until it has become sufficiently fluid to pour. Transfer about 20 ml into a suitable container and maintain it to a temperature of $135 \pm 5.5^{\circ}$ C stirring occasionally to prevent local overheating and allow the entrapped air to escape.

- Charge the viscometer by pouring the prepared sample to within \pm 2 mm of flll line E. Place the charged viscometer in an oven or bath maintained at 135 \pm 5.5°C for a period of 10 \pm 2 min to allow large air bubbles to escape.
- Testing Maintain the bath at the te st temperature within ± O.I°C. Place the charged viscometer vertically in the water bath with the help of a holder so that the uppermost timing mark is at least 2 em below the surface of the bath liquid. Establish a vacuum of 30 ± 0.05 em of mercury in the vacuum system and connect it to the viscometer with the valve closed. After the viscometer has remained in the bath for 30 ± 5 min open the valve and allow the asphalt to flow into the viscometer. Measure to within ± 0.5 s the time required for the leading edge of the meniscus to pass between successive pairs of timing marks. Upon completion of the test, remove the viscometer from the bath and place it in an inverted position in an oven maintained at $135 \pm 5^{\circ}$ C until asphalt is drained off thoroughly from the viscometer. Clean the viscometer thoroughly by rinsing several times with an appropriate solvent completely. Dry the tube by passing a slow stream of filtered dry air through the capillary for 2 minutes. Periodically clean the instrument with chromic acid to remove organic deposits. thoroughly distilled Rinse with water and acetone and dry with clean air.

CALCULATION:

Calculate and report the absolute viscosity to three significant figures, by the following equation:

Viscosity Poises = Kt

where:

K= selected calibration factor, in poise per second; and

t =flow time, in seconds.

RESULT: The viscosity of bitumen by tar viscometer SIGNIFICANCE OF VISCOSITY TEST: Too viscous bitumen would result in inadequate and non-uniform coating of the aggregates. Very low viscosity would again result in inadequate coating as the bitumen will tend to bleed. Therefore viscosity at 135oC is a true reflection of the quality of bond that is likely to be formed with the aggregate.		
The viscosity of bitumen by tar viscometer SIGNIFICANCE OF VISCOSITY TEST: Too viscous bitumen would result in inadequate and non-uniform coating of the aggregates. Very low viscosity would again result in inadequate coating as the bitumen will tend to bleed Therefore viscosity at 135oC is a true reflection of the quality of bond that is likely to be		
 SIGNIFICANCE OF VISCOSITY TEST: Too viscous bitumen would result in inadequate and non-uniform coating of the aggregates. Very low viscosity would again result in inadequate coating as the bitumen will tend to bleed Therefore viscosity at 135oC is a true reflection of the quality of bond that is likely to be 		
 Too viscous bitumen would result in inadequate and non-uniform coating of the aggregates. Very low viscosity would again result in inadequate coating as the bitumen will tend to bleed Therefore viscosity at 135oC is a true reflection of the quality of bond that is likely to be 	THE	viscosity of bitumen by tai viscometer
 Very low viscosity would again result in inadequate coating as the bitumen will tend to bleed Therefore viscosity at 135oC is a true reflection of the quality of bond that is likely to be 	SIG	NIFICANCE OF VISCOSITY TEST:
• Therefore viscosity at 135oC is a true reflection of the quality of bond that is likely to be	•	Too viscous bitumen would result in inadequate and non-uniform coating of the aggregates.
	•	Very low viscosity would again result in inadequate coating as the bitumen will tend to bleed
formed with the aggregate.	•	Therefore viscosity at 135oC is a true reflection of the quality of bond that is likely to be
10111100 (11111 1110 11881 18110)	form	ned with the aggregate.

Viva Questions:

- 1. List the factors that affect the result of a ductility test.
- 2. What do you understand by the term repeatability and reproducibility
- 3. Explain the significance of ductility test.
- 4. What do you understand by the term 30/40 bitumen?
- 5. What are the precautions to be taken while conducting a penetration test?
- 6. What are the applications of penetration test?
- 7. How do you determine the softening point of the bitumen?
- 8. What is softening point?
- 9. If material A has softening point of 56 and B has 42 which binder is good and why?
- 10. Define flash and fire points.
- 11. What is the significance of flash and fire point test?
- 12. What are the parameter that affects the result of flash and fire point tests?
- 13. Briquette mould dimensions are: 14. The grade of Assam petroleum? 15. Minimum ductility value, of S 35 is? 16. Penetration test is to determine of given bitumen 17. The bitumen is softened to a pouring consistency between above the approximatetemperature at which bitumen softens 18. The sample containers are cooled in atmosphere of temperature not lower than for onehour.
- 19. Softening point, thus gives an idea of the temperature at which the bituminous material attains
- 20. with higher softening point may be preferred in the warmer place.
- 21. The temperature at the instant when each of the ball and sample touches the bottom plate of support is recorded as
- 22. To determine softening point of a given bitumen sample__test is done.
- 23. Sample material is heated to a temperature between_____.
- 24. The flash point is the _____at which the vapors of substance momentarily takes fire in the term of a under specified point test.
- 25. The point is the _____ at which the material gets ignited and burns under specified condition of test.
- 26. <u>is</u> the test apparatus for flash and fire test
- 27. Bitumen materials leave out volatiles at ______depending upon their grades
- 28. The heating is done _____ per minute the string is done at a rate of approximately
- 29. Define viscosity
- 30. What are factors effecting viscosity
- 31. The bitumen is softened to a pouring consistency between ____above the approximatetemperature at which bitumen softens
- 32. The sample containers are cooled in atmosphere of temperature not lower _____ than for onehour.

22A. FLASH AND FIRE TEST

AIM: To determine the flash and fire point of the bitumen.

THEORY:

Bitumen materials leave out volatiles at high temperatures depending upon their grades. These volatile vapors catch fire causing flash this condition is very hazardous and it is therefore essential to qualify the temperature for each bitumen grade so that the paving engineers may be restrict the mixing the or application temperature well within the limit. The flash point is the lowest temperature at which the ignition of the volatile vapors occurs when small flame is brought in contact with the vapors of a bituminous product, when the bituminous materials further heated to a high temperature burning of material takes place this is called fire point. Flash point is always less than fire point of bitumen.

Flash point "The flash point is the lowest temperature at which the vapors of substance momentarily takes fire in the term of a under specified point test.

Fire point "The point is the lowest temperature at which the material gets ignited and burns under specified condition of test".

APPARATUS:

- 1) Pensky martens closed tester consists of cup device cover shutter exposure device etc.
- 2) Pensky marten open tester as above with the modification, that the cover of the cup replaced by a clip which encircles the upper rim of the cup and carries the thermometer and test flame.

PROCEDURE:

- 1) All parts of the cup are cleaned and dried thoroughly the test is started. The material is filled in the cup up to a filling mark. The lid is placed to close the cup in a closed system.
- 2) All accessories including thermometer of specified range are suitably fixed. The bitumen sample is then heated. The test flame is lit and adjusted in such a way that the size of a bed is of 4mm diameter. The heating is done at rate of 5 degrees to 6 degrees per minute the string is done at a rate of approximately 60 revolutions per minute. The test flame is applied at intervals depending upon the expected flash and fire points. First application is made at least 17°Cbelow the actual flash point and then at every 1°C to 3°C.

OBSERVATION SHEET:

TYPE OF CUP:

RATE OF

HEATING:

TIME IN MINUTES	TEMPARATURE IN ⁰ C.

RESULTS:	
----------	--

Flash point : Fire point :

22B. SPECIFIC GRAVITY OF BITUMEN

The specific gravity of semi-solid bituminous material, asphalt cements, and soft tar pitches shall be expressed as the ratio of the mass of a given volume of the material at 25 $^{\circ}$ C to that of an equal volume of water at the same temperature. This test is done to determine the specific gravity of semi-solid bitumen road tars, creosote and anthracene oil as per IS: 1202 - 1978.


Apparatus

- Specific gravity bottle of 50 ml capacity, ordinary capillary type with 6 mm diameter neck or wide mouthed capillary type bottle with 25 mm diameter neck.
- Balance having least count of 1g.
- Thermometer.
- Water bath.

Procedure

- 1. The specific gravity bottle is cleaned, dried and weighed along with the stopper.
- 2. It is filled with fresh distilled water, stopper placed and the same is kept in water container for at least half an hour at temperature 27°C.
- 3. The bottle is then removed and cleaned from outside. The specific gravity bottle containing distilled water is now weighed.
- 4. The bituminous material is heated to a pouring temperature and is poured in the above empty bottle taking all the precautions that it is clean and dry before filling sample materials. The material is filled up to the half taking care to prevent entry of air bubbles.
- 5. To permit an escape of air bubbles, the sample bottle is allowed to stand for half an hour at suitable temperature cooled to 27° C and then weighed.
- 6. The remaining space in the specific gravity bottle is filled with distilled water at 27° C, stopper placed and is placed in water container at 27° C.
- 7. The bottle containing bituminous material and containing water is removed, cleaned from outside and is again weighed.

From the weights taken, the specific gravity of bitumen can be found out.



Specific gravity of Bituminous Material

Observation:

$$Specific.Gravity = \frac{\left(W_2 - W_1\right)}{\left(W_3 - W_1\right) - \left(W_4 - W_2\right)}$$

Where,

W1 = Weight of empty specific gravity bottle

W2 = Weight of bottle + bitumen

W3 = Weight of bottle + water


W4 = Weight of bottle + water +bitumen

	Weight of	Weight of	Weight of	Weight of	Specific Gravity =
	empty specific	bottle	bottle +water	bottle + water	$(W_2 - W_1)$
Group	gravity bottle	+bitumen	(W3)	+bitumen	$(W_3 - W_1) - (W_4 - W_2)$
	(W1)	(W2)		(W4)	

RESULT: The specific gravity of semi-solid bituminous material is ______

Viva Questions:

- 29. What do you understand by the term repeatability
- 30. What do you understand by the term reproducibility
- 31. Explain the significance of ductility test.
- 32. What do you understand by the term 30/40 bitumen?
- 33. What are the precautions to be taken while conducting a penetration test?
- 34. What are the applications of penetration test?
- 35. How do you determine the softening point of the bitumen?
- 36. What is softening point?
- 37. If material A has softening point of 56 and B has 42 which binder is good and why?
- 38. Define flash and fire points.
- 39. What is the significance of flash and fire point test?
- 40. What are the parameter that affects the result of flash and fire point tests?
- 41. Briquette mould dimensions are:
- 42. Assam petroleum grade are the following
- 43. Minimum ductility value, of S 35 is _____cm.
- 44. Penetration test is to determine of given bitumen
- 45. with higher softening point may be preferred in the warmer place.
- 46. The temperature at the instant when each of the ball and sample touches the bottom plate of support is recorded as
- 47. To determine softening point of a given bitumen sample_test is done.
- 48. Sample material is heated to a temperature between .
- 49. The flash point is the _____ at which the vapors of substance momentarily takes fire in the term of a under specified point test.
- 50. The point is the _____at which the material gets ignited and burns under specified condition of test.
- 51. is the test apparatus for flash and fire test
- 52. Bitumen materials leave out volatiles at depending upon their grades
- 53. The heating is done _____ per minute the string is done at a rate of approximately 60revolutions per minute
- 54. Why is viscosity important in bitumen?
- 55. Does bitumen have a high or low viscosity?
- 56. What is meant by viscosity of bitumen?
- 57. Is used to conduct the viscosity test on bitumen Mac?
- 58. What is viscosity unit?
- 59. What is viscosity test?
- 60.



NON-DESTRUCTIVE TEST OF CONCRETE

23 REBOUND HAMMER

AIM:


To determine the comprehensive strength of harden concrete by Rebound Hammer.

APPARATUS:

Rebound Hammer.

INTRODUCTION:

When the plunger of rebound hammer is pressed against the surface of the concrete, the spring controlled mass rebounds and the extent of such rebound depends upon the surface hardness of concrete. The surface hardness and therefore the rebound is taken to be related to the compressive strength of the concrete. The rebound is read off along a graduated scale and is designated as the rebound number or rebound index.



PROCEDURE:

- 1. Smoothen the concrete surface with the help of the carborundum stone removing any loosely adhered scale to the concrete surface.
- 2. Rough surfaces resulting from incomplete compaction, loss of grout, spalled or tooled surfaces do not give reliable results and should be avoided.

- 3. The point of impact should be at least 20 mm away from any edge or shape discontinuity.
- 4. The rebound hammer measurements can be taken at any angle, vertically upwards, downwards, horizontal, or any intermediate angle as the situation demands Six readings are taken about each point of observation and the average of these readings after deleting outliners becomes the rebound index for the point of observation.



OBSERVATIONS:

S.NO	REBOUND NUMBER (6 READINGS)	LOCATION OF OBSERVATIONS	COMPRESSIVE STRENGTH (KG/CM2)
1			
2			
3			

RESULTS:

Compressive	strength of	the narden	concrete surface is	
1	\mathcal{C}			

VIVA:				
	1. What do you know about NDT?			
	2. List out various equipment used in NDT?			
	3. During radiography test, which region absorbs less radiation and transmits more?			
	Which test is used to determine dimensions of any object?			
	4. Which test is used to determine dimensions of any object?5. In which type of test the capillary action principle is used?			
	Which test can be performed without skilled labour?			
	What is non - destructive test?			
	What is destructive test?			
	An ultrasonic pulse velocity test is an			
). In this test, the strength and quality of concrete or rock is assessed by measuring the	e		
	of an ultrasonic pulse.			
11.	igher velocities indicate			
12.	ower velocities may indicate			
13.	echanical pulse having an oscillation frequency in range of `			
14.	ne number of cycles per second is the definition of			
15.	discontinuity that occurs during the casting of molten metal which may be caused by the splashing	5,		
	rging, interrupted pouring is			
16.	16. When the motion of the particles of a medium are at right angles to the direction of wave motion, the			
	wave being transmitted is called a			
17.	second name for compression wave is			
18.	ne interference field near the face of a transducer is often referred to as the			
19.	That is the diameter of the plunger?			
20.	That is the importance of this experiment?			
21.	Thich among the following is not a type of Non-destructive testing?			
	Compression test			
	Visual testing			
	Ultrasonic testing			
	Eddy current testing			
22.	That is non-destructive test?			
23.	Which test is used to determine dimensions of any object?			
24.	uring radiography test, which region absorbs less radiation and transmits more?			
25.	Thich of the following statements is/are true for ultrasonic test?			
26.	Thich among the following is the last step in magnetic particle test method?			
27.	which type of test the capillary action principle is used?			
28.	Which test can be performed without skilled labour?			
29.	That is the first step involved in the process of preparation of test sample of material?			
30.	Thich of the following compound is used for fine polishing?			
31.	That is destructive test?			
32.	entify the type of destructive testing.			
33.	hich test can be performed without skilled labor?			
34.	34. Compressive strength of hardened concrete is done by			
	is about times the tensile stress determined by the splitting test.			
36.	ratio of core height-to-diameter of gives a standard cylinder test.			

37. In Concrete core test the strength is at the top and at the bottom.
38. What is nondestructive test?
39. During radiography test, which region absorbs less radiation and transmits more?
40. Which of the following compound is used for fine polishing?
a) Aluminum oxide
b) Nitric oxide c) Silicon carbide
d) Iron oxide
41. How can we prevent cracks in concrete structures?
42. What is the maximum w/c ratio?
43. Which can be the possible option for cracking in the building?
44. Is it possible to have 0% crack in our building?
45. Plastic shrinkage cracking occurs in hours after placing.
46. Which one can't be the reason for the shrinkage of concrete?
47. Evaluation of cracks be determined before cracking.
48. Evaluation of cracks be determined after cracking.
49. Symptoms for acid attack?
50. Symptoms for aggressive water attack?

24. ULTRASOUND PULSE VELOCITY (UPV)

AIM:

To determine the time of travel of an ultrasonic pulse passing through the concrete.

APPARATUS:

Ultrasound pulse velocity

INTRODUCTION:

This test is done to assess the quality of concrete by ultrasonic pulse velocity method as per IS: 13311 (Part 1) - 1992. The underlying principle of this test is – The method consists of measuring the time of travel of an ultrasonic pulse passing through the concrete being tested. Comparatively higher velocity is obtained when concrete quality is good in terms of density, uniformity, homogeneity etc.

PROCEDURE:

- 1. Preparing for use: Before switching on the "V" meter, the transducers should be connected to the sockets marked "TRAN" and" REC". The "V" meter may be operated with either:
- a) the internal battery, b) an external battery or c) the A.C line.
- 2. Set reference: A reference bar is provided to check the instrument zero. The pulse time for the bar is engraved on it. Apply a smear of grease to the transducer faces before placing it on the opposite ends of the bar. Adjust the "SET REF" control until the reference bar transit time is obtained on the instrument readout.
- 3. Range selection: For maximum accuracy, it is recommended that the 0.1 microsecond range be selected for path length up to 400mm.
- 4. **Pulse velocity:** Having determined the most suitable test points on the material to be tested, make careful measurement of the path length "L".
- 5. Apply couplant to the surfaces of the transducers and press it hard onto the surface of the material. Do not move the transducers while a reading is being taken, as this can generate noise signals and errors in measurements. Continue holding the transducers onto the surface of the material until a consistent reading appears on the display, which is the time in microsecond for the ultrasonic pulse to travel the distance "L". The mean value of the display readings should be taken when the units digit hunts between two values.

Pulse velocity = (Path length/Travel time).

6. **Separation of transducer leads:** It is advisable to prevent the two transducer leads from coming into close contact with each other when the transit time measurements are being taken. If this is not done, the receiver lead might pick-up unwanted signals from the transmitter lead and this would result in an incorrect display of the transit time.

RESULT:

The quality of concrete in terms of uniformity, incidence or absence of internal flaws, cracks and segregation, etc, indicative of the level of workmanship employed, can thus be assessed using the guidelines given below, which have been evolved for characterizing the quality of concrete in structures in terms of the ultrasonic pulse velocity.

PULSE/VELOCITY (KM/SECOND)	CONCRETE QUALITY(GRADING)
ABOVE 4.5	EXCELLENT
3.5 TO 4.5	GOOD
3.0 TO 3.5	MEDIUM
BELOW 3.0	DOUBTFUL

VIVA	A :	
1.	What are the types of destructive and non – destructive tests	?
2.	What are the different types of hardness tests are carried out	?
3.	What do you know about NDT?	
4.	List out various equipment used in NDT?	
5.	What is non - destructive test?	
6.	What is destructive test?	
7. 8.	In which type of test the capillary action principle is used? How pulse velocity is calculated?	
9.	The pulse velocity in concrete may be influenced by	
10.	Which is the last step in magnetic particle test method?	
11.	During radiography test, which region absorbs less radiation	and transmits more
12.	Which test is used to determine dimensions of any object?	
13.	What Are the Advantages of Ultrasonic Testing?	
14.	What Are the Potential Limitations of Ultrasonic Testing?	
15.	What Is an Ultrasonic Transducer?	
16.	What Is an Ultrasonic Thickness Gage?	
17.	How Accurate Is Ultrasonic Thickness Gaging?	
18.	What Is an Ultrasonic Flaw Detector?	
19.	What Is Vibration Analysis?	
20.	What Sort of Materials Can Be Tested?	
21.	Symptoms for aggressive ACR reaction?	
22.	Symptoms for aggressive ASR?	
23.	What should be the minimum water cement ratio?	
24.	Cement not more than months old should be u	sed.
25.	Powder epoxy is fusion bonded to bar at about	_0C temperature.
26.	At the construction stage, binding wires	
27.	Creep is to the strength of concrete.	
28.	What is elastic strains?	
29.	Which test is used to determine dimensions of any object	?
a) Ult	trasonic test	
b) To	orsion test	
c) Ed	ldy current test	
d) Co	ompression test	
30.	Identify the type of destructive testing.	
a) Ra	ndiographic test	
b) Dy	ye penetrant test	
c) Cre	eep test	

d) Visual testing				
31. C	Compressive strength of hardened concrete is done by			
32. I	In the soundness test a specimen of hardened cement paste is for a fixed time.			
33. Lo	oss on Ignition (L.O.I.) is the loss in weight of cement after being heated to			
34. C	On cooling below 1250°C, C ₃ S decomposes			
35. W	What is final setting time?			
36. Tl	he loss in weight should not exceed percent when tested with sodium sulphate and			
percent v	with magnesium sulphate solution.			
37. If	60% aggregates doesn't pass through the 2.36mm sieve, then what would be the value of			
Aggrega	ate impact value?			
38. IS	S code for Specification for ordinary Portland cement, 33 grade?			
39. IS	S code for Specification for coarse and fine aggregates from natural sources for concrete?			
40. IS	S code for Specification for Portland slag cement?			
41. IS	S Code of practice for plain and reinforced concrete.			
	S 457:1957 is for			
43. IS	S 1489(Part 1):1991 is for			
44. IS	S 1489(Part 2):1991 is for			
45. IS	S 1727:1967 is for			
46. IS	S 650:1991 is for			
47. IS	S 1199:1959 is for			
48. V	What should be the minimum water cement ratio?			
49. P	Powder epoxy is fusion bonded to bar at about0C temperature.			
50. A	at the construction stage, binding wires			

BEYOND THE SYLLABUS LAB EXPERIMENT

Determining Concrete Compressive Strength by Accelerated Curing Test (IS: 9013) AIM: Determine the compressive strength of concrete cubnes by acceerated curing method. APPARTUS:

Accelerated curing tank

PROCEDURE:

As per BIS (IS 516) the compressive strength of a concrete mix is determined by curing concrete cubes (150mm) for 28 days, temperature maintained at $27+/-2^{\circ}$ C. This test determines the grade of concrete.

But under special requirements (time constraints) to determine grade of concrete it may not be feasible to wait as long as 28 days, BIS has recommended accelerated curing test (on accelerated-cured concrete test specimens) to determine grade of concrete in about 28 hrs, governed by IS: 9013.

Although, Indicative strength can be achieved by testing the cubes after 3 days (50% of 28 days strength) and 7 days (60% of 28 days strength) from casting, a more standard method is commonly called Accelerated Curing Test.

Accelerated Curing is a method used to get high early compressive strength in concrete structure. Accelerated Curing is mostly used in pre-cast industry where high early strength reduces costs, by decreasing the formwork removal time, also repair works are accelerated curing, in order to make its functional at early age.

Raising the temperature of curing water speeds up the cement hydration process, thereby both curing of concrete and achieving high early compressive strength.

The following two methods can be used for Accelerated Curing Test determining Compressive Strength of Concrete.

- 1. Warm-Water Method
- 2. Boiling Water Method

Boiling Water Method is commonly used for achieving accelerated strength.



Accelerated curing tank used in laboratory for concrete testing

accelarated Curing by Boiling Water Method


- Test specimens are to be casted and left undisturbed for 23 hours +/- 15 mins in moist air of atleast 90% humidity and at a temperature of 27 +/- 2 deg C
- The test specimens are lowered into the curing tank and totally immersed in water The test specimens are lowered into the curing tank and totally immersed in water for a period 3.5 hours +/- 5 mins. The water in the curing tank should be maintained at a temperature of 100 deg C.
- After curing for 3.5 hours in the curing tank, the test specimens are to be removed from the boiling water and cooled by immersing them in a cooling tank with water at a temperature of 27 +/- 2 deg C for 2 hours. The cubes are to be remolded once cooled
- The test specimens once removed from the curing tanks are to be tested for their compressive strength in accordance to IS: 516.
- Based on the correlation obtained between normally cured concrete and accelerated cured concrete, the following formula are derived for 28 days compressive strength of concrete mix:

RESULT:

 R_{28} (Strength at 28 days) = 8.09 + 1.64 Ra

Where Ra is the average compressive strength of concrete test specimens used in the Accelerated curing test

The 28 days compressive strength of the concrete mix can be calculated by using the following formula.



VIVA

- 1. In Accelerated curing test Ra is meant for _____.
- 2. Commonly used accelerated curing method is _____
- 3. How many methods are there for accelerated curing _____
- 4. The reference code for accelerated curing method is ______
- 5. The units of Accelerated strength is
- 6. The ability of the material to resist stress without failure is called _____
- 7. "The shape of specimen used in compression test is Cube and cylinder".
- 8. Equipment used to test Compression Strength of Concrete?
- 9. Size of Concrete Cubes?
- 10. No. of Cube samples required for testing Compression Strength for 100 m3 of concrete?
- 11. List the various methods of compacting of concrete?
- 12. How is compressive strength of concrete is measured?
- 13. What should be the compressive strength of concrete at 7 days?
- 14. What is F of concrete?

 15. What is the compressive strength of M₃₀ grade concrete? 16. How long does it take to concrete to reach its full strength? 17. What should be the compressive strength of concrete at 14 days? 18. What should be the compressive strength of concrete at 28 days? 19. What is standard deviation for M₄₀ grade? 20. What happens if we test a wet cube in a compressive strength test machine? 21. Tensile test can be performed on 22. Which machine records the change in length of specimen? 23. The ability of the material to resist stress without failure is called
24. In universal testing machine, for a circular section specimen, the gauge length is taken to be
25. "The shape of specimen used in compression test is Cube and cylinder".
26. During compression test of cast iron, the failure occurs i.e. the crack appears along the
20. During compression test of east from, the famore occurs her the crack appears along the
27. The property of a material that resists penetration or indentation by means of abrasion or scratching is known as
28. The indenter used in Brinell hardness test is a
29. For hardness test of copper in Brinell hardness tester, the diameter of ball is
30. In charpy test specimen, the angle of v-notch section is
31. The breaking up of cohesion in a mass of concrete is called
32. The separation of water or water-cement mixture from the freshly mixed concrete is known as
bleeding.
33. The continuous strain, which the concrete undergoes due to application of external loads, is called
34. Harshness in concrete is due to the excess of
35. In order to avoid segregation, the concrete should not be thrown from a height (TRUE / FALSE)
36. Reinforced cement concrete is equally strong in taking
37. Plain cement concrete is strong in taking
38. Accelerated curing importance is
39. Regression Equation is
40. What is R28 Indicate